

Instructions for Overslung/Underslung Conversion kits

K71-384-00 for 2³/₈" diameter tube

K71-385-00 for 3" diameter tube

**WARNING: Failure to follow recommendations
may result in serious bodily injury or death.**

1. Jack up trailer and secure on adequate capacity jack stands.
*Follow the trailer manufacturer's recommendations
for lifting and supporting the unit.*
Do not lift or place supports on any part of the suspension system.
*CAUTION: Never crawl under your trailer unless it is resting on
properly placed jack stands.*
2. Remove wheels and tires from hubs.
3. Mark top of axle with paint or chalk for reference during
reinstallation.
4. Disconnect brake wires from the harness at the connectors.
5. Support axle. Remove U-bolt nuts, U-bolts and tie plates. Discard U-
bolt nuts and U-bolts.
6. Remove spring eye bolts from front and rear hangers, drop front of
spring. NOTE: Only the front spring eye bolts need to be removed on
single axle units.
7. Inspect hangers, spring seats, under side of trailer frame and all
welds for wear. Correct if necessary.
8. Place axle in new position, with top of axle (previously marked) still
up. Proper axle placement is important for brake operation and
vehicle stability.
9. Place top mount spring pad from kit on top of axle. Adjust nuts so
that top of pad is parallel with bottom of original welded spring pad
(within 1/32") and that the pad is firmly seated on the tube, i.e. use the
adjusting nuts to insure parallelism, not height. Insure both adjusting
nuts contact original spring pad. (To minimize the possibility of axle
slippage, it is strongly recommended the spring pads be tack welded
in place.)

NOTE: The adjusting nuts serve two purposes:

1. Aids in establishing and keeping new spring pad parallel
with original spring pad.
2. Transfer road shock and brake torque from new unwelded
spring pad to original welded spring pad.

Instructions for Overslung/Underslung Conversion kits

K71-384-00 for 2³/₈" diameter tube

K71-385-00 for 3" diameter tube

10. Locate spring center bolt in center hole of spring pad.
11. Reattach springs using NEW U-bolts, nuts and tie plates provided in
kit. Torque U-bolt nuts to 50-60 lb.-ft.
12. Reattach axle and spring assembly with spring eye bolts. Torque
nuts on shoulder type spring eye bolts to 30-50 lb.-ft. Tighten ⁹/₁₆"
spring eye bolt locknuts to "snug fit only."
13. Reattach brake lines using connections comparable to the original
equipment. Make sure the lines are lengthened as necessary to
ensure proper brake function at the limits of the axles' articulation.
Failure to do so may cause the brakes to become disconnected with
subsequent loss of braking.

For electric brakes, Dexter recommends using crimp type, corrosion
resistant connectors available in kit K71-399-00. Verify proper brake
current draw (typically 3.0 amps per magnet.)
14. Reinstall wheel and tire, lower vehicle to ground. Recheck wheel nut
and U-bolt nut torque. Check for proper braking function. Recheck
wheel nut torque periodically thereafter.

NOTE: When converting from underslung to overslung, the installation of
bump stops to prevent suspension over travel and resulting possible
spring damage or breakage is highly recommended. Axle travel
should be limited to the amount available prior to mounting conver-
sion.

When converting from overslung to underslung, adequate suspen-
sion travel is required to prevent the axle(s) from bottoming out
prematurely, resulting in axle bending.



DEXTER AXLE

2900 Industrial Parkway East

Elkhart, IN 46516

219-295-8666 fax 219-295-7888

www.dexteraxle.com

059-551-00

Rev A

7/01