

Troubleshooting Guide- Smart Start Solenoid Replacement Kit #7055 Trailer Installation April 2008

To replace Smart Start solenoid with Smart Start Replacement Kit #7055

- 1) Remove and protect power leads to the Smart Start solenoid
- 2) Cut two (2) red wires to directional valve coil and four (4) wires from the switchgear box.
- 3) Reconnect as shown using butt connectors.

Note: valve coil wiring is not polarity sensitive

