

Installation Illustrations CR-114N Cargo Rack

Parts List:

- 2 Hitch Rack (left & right)
- 1 Long Base shaft
- 1 Short Base shaft w/reflector
- 1 Support Brace
- 4 2 3/4" x 3/8" Hex Bolts
- 2 1 1/2" x 5/16" Hex Bolts
- 4 3/8" Hex nuts
- 4 3/8" Flat washers
- 4 3/8" Lock washers
- 2 5/16" Flat washers
- 2 5/16" Lock washers
- 2 5/16" Hex nuts

Tools Needed:

14mm socket 14mm wrench 17mm socket

17mm wrench Ratchet wrench

Important:

Maximum load rating 350lb.

Installation Instructions:

- 1. Align the two side brackets with the holes on the long base shaft, apply the 3/8" hex bolts w/nut & washers to assemble the three pieces into one unit (As shown in illustration). Slide the short base shaft into the end of the rack and apply a 3/8" hex bolt w/nut and washers. Hand tighten for now.
- 2. Install the support bracket to the rack and apply the 5/16" hex bolts w/nuts and washers.
- 3. Tighten all screws firmly.

Caution: Never exceed the Tongue Weight Capacity of your hitch!

