



Installation Instructions

SuperSteer® Rear Trac Bar

Part #SS300TP

This installation instruction is provided when installing the SS300 Rear Trac Bar to the chassis, which has the exhaust pipe behind the rear wheel.

1. First check in front of the left rear wheel for clearance around compartments, plumbing and electrical. Make sure to use heat shielding and leave plenty of clearance.
2. Hold the new tailpipe up to old exhaust system to determine where to make a cut. Remember: leaves extra length for a slip fit. Remove exhaust and hangers as needed. Slip pipe on and position U-clamp and tack weld new pipe.
3. Install tailpipe hanger at frame.
4. Install heat shields. Remember: exhaust will expand with heat, so leave extra room towards the rear of the pipe and install hanger so it can flex.
5. Start the engine and check for leaks, rattles, and clearance.

Thank you for your SuperSteer® purchase.
888-898-3281