

## SLIDEOUTS

Tools Required (Fig. 1)	
1	Drill
1	1/4" Drill Bit
1	7/16" Wrench
1	9/16" Wrench

Fig. 1



Fig. 2

1. Rotate the cross shaft 90 degrees and drill a new 1/4" hole (Fig. 2).



Fig. 3

2. Reattach motor and cross shaft using:
  - Bolt - 1/4" - 20x2 Cap Screw GR8 Yellow Zinc
  - Nut - 1/4" - 20 Top Lock GR2 Zinc

