



DOUBLETREE PURGING PROCEDURE WITH LTM BEDSLIDE

1. Place jack stands under coach frame or pinbox.
2. Extend Bedslide.
3. Manually override Bedroom EIRC (clockwise). DO NOT EXTEND LIVINGROOM OR KITCHEN SLIDES.
4. Connect manual purge hose to quick disconnect on retract side of the pump (Black hose side where EIRC is located).
5. Remove Fill Cap.
6. Place clear hose in the fill hole of the reservoir.
7. Open star handled valve on purge unit.
8. Press EXTEND side of Bedroom Slide out switch for a minimum of 30 seconds and no more than 45 seconds.
9. Check the reservoir for foam. Foam demonstrates air in the system.
10. Remove purge hose from quick retract side quick disconnect.
11. Connect purge hose to opposite (extend side) quick disconnect.
12. Press RETRACT side of Bedroom Slideout Switch.
13. Check the reservoir for foam.
14. Remove purge hose from quick disconnect and clear hose from fill hole.
15. Turn Bedroom Slideout manual override back to normal operation (counterclockwise).