



1

RELEASE SIDE TOGGLES AND UNZIP THE COLLAPSED COOLER TO OPEN



2

FOAM PANELS FOLD UP AND VELCRO TOGETHER TO PROVIDE INSULATION AND STRUCTURE



3

PULL WATERPROOF COOLER LINER UP FOLD OVER AND VELCRO TO FOAM PANELS



4

PULL UP EXTERIOR FABRIC AND VELCRO TO FOAM PANELS



5

ENJOY!

