

2007-14 Silverado/Sierra/Tahoe/Yukon (400130) & 14+ Silverado/Sierra (400140) Upper Mirror Cover Installation Instructions

Congratulations on your purchase of a high quality PUTCO product. Should you need any application or technical assistance, feel free to call us at: 1-800-357-9261
Monday-Friday 8:00 a.m. - 5:00 p.m. (Central Standard Time)
Contact your PUTCO dealer for other quality accessories.

Please read all instructions before installation and to check to see that all parts are included.

KIT CONTENTS:	
Description	Qty.
Driver Mirror Cover	1
Passenger Mirror Cover	1

Tools Needed:

- Flat Head Screw Driver
- Masking Tape

Upper Mirror Cover Installation

1. Remove part from packaging. Check to see if all parts from above table of kit contents are included.



2. Place masking tape along bottom edge of the factory mirror cover. (Driver side is pictured)



3. Use flat head screw driver to pry on the lower portion of the factory mirror cover until the clips release



4. Pull up and out on loose mirror cover until cover is removed



5. Remove masking tape, place Putco mirror cover in factory location and press firmly until all snaps are fully engaged. Repeat steps 2-5 on Passenger side

LIMITED 90 DAY WARRANTY

Putco guarantees its Stainless Steel and Aluminum products against defects in workmanship and material for as long as you own your vehicle. All painted products have a 90 day warranty on the painted surface. Any defects resulting from faulty material or workmanship will be warranted by Putco and repaired or replaced at our discretion. Putco assumes no extra labor costs. Damages caused by freight carriers, improper installation, misuse, collision, or neglect will not be warranted by Putco.