

## 2017+ Super Duty Emblem Kit Installation Instructions

Congratulations on your purchase of a high quality PUTCO product. Should you need any application or technical assistance, feel free to call us at: 1-800-247-3974  
 Monday-Friday 8:00 a.m. - 5:00 p.m. (Central Standard Time)

Contact your PUTCO dealer for other quality accessories.

**Please read all instructions before installation and to check to see that all parts are included.**

KIT CONTENTS:	
Description	Qty.
Front Emblem	1
Rear Emblem	1
Bolt Kit	1
Alcohol Prep Pad	1

### Tools Needed:

- 10mm Wrench
- 3/8" Wrench
- T25 Torx
- Plastic Pry Bar
- Flat Head Screw Driver

### Front Emblem Installation

1. Remove Emblem kit from packaging. Check to see if all parts from above kit contents table are included.



2. Remove plastic cover by removing 13 retaining clips (number of retaining clips may vary) with flat head screw driver (locations shown above).



3. Once cover is removed, remove the top 8 grille screws with 10mm wrench (location shown above)



4. Pull upper grille forward to release upper grille clips. Once out, release 4 bottom clips with a flat head screwdriver. Passenger side locations are shown. Repeat on driver side



5. Remove grille. Once grille is removed, Lay grille on flat surface (Protect grille front face) remove 3 10mm nuts to release front emblem. (locations shown above)

#### LIMITED 90 DAY WARRANTY

Putco guarantees it's Stainless Steel and Aluminum products against defects in workmanship and material for as long as you own your vehicle. All painted products have a 90 day warranty on the painted surface. Any defects resulting from faulty material or workmanship will be warranted by Putco and repaired or replaced at our discretion. Putco assumes no extra labor costs. Damages caused by freight carriers, improper installation, misuse, collision, or neglect will not be warranted by Putco. **Putco is not liable for any vehicle damage resulting from the installation of our Hood Shield.**



6. Insert threaded studs into the back of larger front emblem.



7. Slide emblem through holes in grille and mount using the rest of the supplied hardware. Use 3/8" wrench to tighten hardware. Reinsert grille and it's components.

## Rear Emblem Installation



1. Pry off factory rear emblem with a plastic pry bar. Be very careful not to damage the paint. Tape can be used to protect paint. There a 4 plastic clips and tape that hold emblem on.



2. Clean area circled above with alcohol prep pad.



3. Open tailgate and remove 8-T25 screws on access panel. Set panel aside.



4. Unbolt tailgate opening hardware (using a 10mm wrench) inside tailgate to get clearance to back of emblem area.

### LIMITED 90 DAY WARRANTY

Putco guarantees it's Stainless Steel and Aluminum products against defects in workmanship and material for as long as you own your vehicle. All painted products have a 90 day warranty on the painted surface. Any defects resulting from faulty material or workmanship will be warranted by Putco and repaired or replaced at our discretion. Putco assumes no extra labor costs. Damages caused by freight carriers, improper installation, misuse, collision, or neglect will not be warranted by Putco. **Putco is not liable for any vehicle damage resulting from the installation of our Hood Shield.**



5. Insert supplied threaded studs to upper holes on smaller rear emblem. Lower threaded holes are not used.



6. Pull red tape liner on tape on rear of emblem. Place the emblem's threaded studs into upper rear holes on back of tailgate



7. While holding emblem in place use the rest of supplied hardware to secure emblem from inside tailgate as shown above.

8. Remount tailgate opening hardware and place access panel back on tailgate.

**Note: PUTCO recommends applying a high quality automotive wax to maintain the original appearance on your new Ford Emblems**

**CAUTION: Take the proper precautions to protect the face of the grille from cosmetic damage.**

**LIMITED 90 DAY WARRANTY**

Putco guarantees its Stainless Steel and Aluminum products against defects in workmanship and material for as long as you own your vehicle. All painted products have a 90 day warranty on the painted surface. Any defects resulting from faulty material or workmanship will be warranted by Putco and repaired or replaced at our discretion. Putco assumes no extra labor costs. Damages caused by freight carriers, improper installation, misuse, collision, or neglect will not be warranted by Putco.