



1) Remove any existing start cap, start relay, & any dashed wiring shown.

2) Connect the BLACK wire from the ES to the same splice where the existing PUR meets the BLK.

3) Remove the WHT wire leading to the compressor RUN winding from the run cap, and splice it to the BROWN wire from the ES.

**EasyStart**

4) Connect the WHITE wire from the ES to run cap on the side with the existing YEL wire.

5) Connect the ORANGE wire from the ES to run cap on the other side with the existing RED wire.

6) Perform the first 5 learning startups on utility power, waiting 3 min between each.