



# SnapPad HiWay

## Installation Instructions

**Congratulations on joining the SnapPad family!**

### Disclaimer

- SnapPads are an aftermarket RV accessory and as such it is the responsibility of the RV owner to insure they are an appropriate and safe addition to their RV.
- Origen RV Accessories LTD shall not be liable for any special, incidental, indirect or consequential damages whatsoever (including but not limited to, labor, installation, charges, damages to associated equipment, RV, trailer, towing or following vehicle) arising from the use or inability to use or install the product.
- Use extreme caution when installing and using SnapPad. Origen RV Accessories LTD is not responsible or liable in any way for any indirect or direct injury sustained during installation or future use of the product.
- Installing SnapPad products on non-compatible leveling systems will result in the voiding of the warranty and can lead to product failure, property damage, or injury. Origen is not responsible for any issues arising from the use of our products on non-compatible systems.
- SnapPads are designed to be installed once. Do not remove and re-install as this will also void your warranty.



# HiWay 8 Installation Instructions

## \*\*\*Important Notes\*\*\*

\*\*\* These instructions are specific for HWH landing feet that are 8" in diameter\*\*\*

\*\*\*For HiWay Plus follow these instructions for your front jacks\*\*\*

\*\*\*HiWay 8 is designed with large "bracket slots" to accommodate the spring bracket tabs on the edge of your landing foot or the cross beam between your front jacks.\*\*\*

\*\*\*GRAB A HELPER - Installation is safer and easier with 2\*\*\*



Installation time: 3 - 6 minutes per pad.

Video instructions can be found on our website [www.rvsnappad.com](http://www.rvsnappad.com) or on YouTube - Search 'SnapPad HiWay install video'.

1. Snap Pad installation is best performed on a level or near level surface - preferably a hard surface (concrete or asphalt). Wheel chocks can be placed in front of and behind the RV wheels for additional safety.
2. \*\*\*Spread a small bead of concentrated dish soap or grease around the lip of the SnapPad to aid installation.\*\*\*
3. \*\*\*Most motorhomes will release their airbags prior to engaging the jacks. This will lower the entire RV at the beginning of the leveling process. You may place your first SnapPad prior to this, however be careful to not get caught underneath your RV during the lowering process!\*\*\*

**4. \*\*\* Some landing feet will have the spring brackets welded to the outside lip. When lining up your SnapPad, ensure the spring brackets are inline with the brackets slots on the SnapPad. This is critical to make sure your SnapPads install properly. Certain models will have the spring brackets welded inside the lip (closer to the center). In this case the bracket slots can be aligned in any direction. \*\*\***

**\*\*\* Cross beam consideration - on certain Tiffins the front jacks will have a cross beam between them. Your SnapPads may or may not hit this beam when retracted. If so, and your landing feet do not have the spring brackets welded on the lip, then you may spin your SnapPads to allow the bracket slot to line up with the cross beam. \*\*\* For other questions or clarification call technical support at 1.855.762.7723 ext. 3.**

**5.** Typically one side will level first. Take note which side that is and start there. Install one SnapPad at a time and/or use the manual jack operation if possible. Refer to your owners manual for instructions.

**6.** Most jacks are 18" - 24" under your RV. Use a tool such as a broomstick to align/adjust your SnapPads may be necessary.

**7.** Once aligned, begin lowering your jack. Keep a watchful eye on the landing foot as it extends. Stop extending when the foot is about 1 to 3 inches from the your SnapPad. **Double check to make sure it is centered and (if necessary) your bracket slots are lined up with the spring brackets.** Re-align as needed and then continue extending the landing gear to complete installation. **\*\*\*KEEP YOUR FINGERS AND ANY FOREIGN OBJECTS CLEAR WHEN LOWERING THE JACK INTO PLACE.\*\*\***

**8.** You should hear a distinctive 'Snap' as the lip engages. **\*\*\*Visually confirm the lip is fully engaged around the perimeter of the landing foot.\*\*\***

**9. \*\*\*If your lip hasn't fully engaged raise your jack and place a shim (small piece of wood) under the side that hasn't engaged. Lower your jack again until that side snaps into place. Search 'RV SnapPad Uneven Ground Installation' on youtube for an example.\*\*\***

**10.** Wipe off excess soap or grease and repeat installation process, in sequence, on your remaining jacks.

# HiWay 10 Installation Instructions

## \*\*\*Important Notes\*\*\*

\*\*\* These instructions are specific for HWH & Atwood landing feet that are 10" in diameter\*\*\*

\*\*\* For HiWay Plus use these instructions on the rear jacks\*\*\*

\*\*\*GRAB A HELPER - Installation is safer and easier with 2\*\*\*



Installation time: 3 - 6 minutes per pad.

Video instructions can be found on our website [www.rvsnappad.com](http://www.rvsnappad.com) or on YouTube - Search 'SnapPad HiWay install vid'.

1. Snap Pad installation is best performed on a level or near level surface - preferably a hard surface (concrete or asphalt). Wheel chocks can be placed in front of and behind the RV wheels for additional safety.
2. \*\*\*Spread a small bead of concentrated dish soap or grease around the lip of the SnapPad to aid installation.\*\*\*
3. \*\*\*Most motorhomes will release their airbags prior to engaging the jacks. This will lower the entire RV at the beginning of the leveling process. You may place your first SnapPad prior to this however be careful to not get caught underneath your RV during the lowering process!\*\*\*



**4. \*\*\* Unlike HiWay 8's you have water drainage channels which can be aligned in any direction. We recommend perpendicular to your spring brackets (like in the above picture) although you can set them in any configuration\*\*\***

**5.** Generally one side will level first, take note which side that is and start there. Install one SnapPad at a time and/or use the manual jack operation if possible. Refer to your owners manual for instructions.

**6.** Most jacks are 18" - 24" under your RV. A tool such as a broomstick to align/adjust your SnapPads may be necessary.

**7.** Once aligned begin lowering your jack. Keep a watchful eye on the landing foot as it extends. Stop extending when the foot is about 1 to 3 inches from the your SnapPad. Double check to make sure it is centered, re-align if necessary and then continue extending the landing gear to complete installation. **\*\*\*KEEP YOUR FINGERS AND ANY FOREIGN OBJECTS CLEAR WHEN LOWERING THE JACK INTO PLACE.\*\*\***

**8.** You should hear a distinctive 'Snap' as the lip engages. **\*\*\*Visually confirm the lip is fully engaged around the perimeter of the landing foot.\*\*\***

**9. \*\*\*If your lip hasn't fully engaged raise your jack and place a shim (small piece of wood) under the side that hasn't engaged. Lower your jack again until that side snaps into place. Search 'RV SnapPad Uneven Ground Installation' on youtube for an example.\*\*\***

**10.** Wipe off excess soap or grease and repeat installation process, in sequence, on your remaining jacks.

### HAVE QUESTIONS OR NEED ASSISTANCE?

Feel free to contact us anytime.

Phone: **1.855.762.7723**


Email: **info@rvsnappad.com**

Website: **RVSnapPad.com**

### ON SOCIAL MEDIA?

 **@ RVSnapPad**

 **@ SnapPad**

 **@ rv\_snappad**



## Helpful Hints

- It's best (and easiest) to install your SnapPads one at a time on a level, hard surface.
- Each leveling system will have it's own manual operation function. Please refer to your owners manual for specific directions.
- Grab a helper! It's safer, faster, and more efficient with two people
- Install each SnapPad individually and visually confirm the reinforced lip has engaged on the complete diameter. It is critical your SnapPad has been installed fully and correctly.
- Standing water? No problem! Your SnapPads have a built in drainage channel.
- Installs easier in warmer weather. 50 degrees F +.



## SnapPad Info & Statistics

- Once installed they add an extra 1" to your jack thickness
- You're helping our environment! SnapPads are made from American recycled tires. That means SnapPads are not only durable and versatile but environmentally
- Will work on any type of surface, level or uneven, including: Asphalt - Concrete - Grass - Gravel - Mud - Sand - Resin - Ice - Snow.
- Scientifically tested to maintain integrity at over 10,000 lbs of pressure.
- It takes over 1,300 lbs. of vertical pressure to install your SnapPads. This ensures no matter how far off the beaten path you venture, your SnapPads will be there with you.
- Proudly manufactured & shipped from Mishawaka, Indiana, USA!

### SAFETY

*Your SnapPad's have been tested to withstand over 50x the force of gravity. Which means you could hit the biggest pothole of your life at 60 MPH and your SnapPads will remain firmly fasten to your jacks.*

### HAVE QUESTIONS OR NEED ASSISTANCE?

Feel free to contact us anytime.

Phone: **1.855.762.7723**


Email: **info@rvsnappad.com**

Website: **RVSnapPad.com**

### ON SOCIAL MEDIA?

 **@ RVSnapPad**

 **@ SnapPad**

 **@ rv\_snappad**

# Warranty Info

Congratulations on your purchase of the first and only permanent jack pads!

## ***What is covered and for how long?***

Origen RV Accessories LTD offers a 2 year extended warranty on both performance and defects in material and workmanship. Should your product fail within a 2 year time frame, Origen RV Accessories LTD will replace your pad free of charge.

## ***Conditions***

- Origen RV Accessories LTD will replace any defective products within the acceptable 2 year window, starting from the purchase date.
- Provide an emailed picture of product defect.
- Should you have accidentally ordered the wrong version, ship them back for a full refund.
- Product must be shipped back to Origen RV Accessories LTD manufacturing facility at owners cost, meaning **you pay the shipping charges**. See address below.

***Attn: Don Zimmerman - 605 S Laurel St, Mishawaka, IN 46544, USA***

- Confirmation that defect is not from repeated installation or misuse in any way.

## **Disclaimer**

- **SnapPads are an aftermarket RV accessory and as such it is the responsibility of the RV owner to insure they are an appropriate and safe addition to their RV.**
- **Origen RV Accessories LTD shall not be liable for any special, incidental, indirect or consequential damages whatsoever (including but not limited to, labor, installation, charges, damages to associated equipment, RV, trailer, towing or following vehicle) arising from the use or inability to use or install the product.**
- **Use extreme caution when installing and using SnapPad. Origen RV Accessories LTD is not responsible or liable in any way for any indirect or direct injury sustained during installation or future use of the product.**
- **Installing SnapPad products on non-compatible leveling systems will result in the voiding of the warranty and can lead to product failure, property damage, or injury. Origen is not responsible for any issues arising from the use of our products on non-compatible systems.**
- **SnapPads are designed to be installed once. Do not remove and re-install as this will also void your warranty.**