


Brake Controls



HUSKY Custom Wiring Harnesses for Brake Controls

For the **Husky Quest[®], Escort[®] Digital and Ascend**. These fit all Husky brake controls that have a similar shaped plug. Simply attach the adapter to the Husky brake control. The safest/easiest way to wire a brake control to your tow-prepped vehicle. Clamshell packed.

Husky Custom Wiring Harness with OEM specific under-dash connector and brake control mating connector			Harness with OEM specific under-dash connector and bare wires only for universal application to brake controls without a connector
	Square Connector	Flat Connector	
Fits: CHEVY / GMC / CADILLAC 1999-2002 Silverado; 2000-02 Suburban/Tahoe; 2002 Avalanche; 1999-02 Denali; 2000-02 Denali XL; 1999-2006 Sierra; 2000-02 Yukon/Yukon XL; 2000-02 Escalade	31708	31865	
Fits: CHEVY / GMC / CADILLAC / HUMMER 2003-2006 Silverado; 2007 Silverado Classic; 2003-06 Suburban/Tahoe; 2003-06 Avalanche; 2003-06 Denali/Sierra; 2007 Sierra Classic; 2003-06 Yukon; 2003-06 Escalade; 2003-07 H2; 2005-07 H2 SUT	31710	31866	31691
NEW! Fits: CHEVY / GMC 2014-15 Silverado/Sierra		32253	
Fits: GM / CHEVY / BUICK / SATURN 2008-14 Acadia; 2008-14 Traverse; 2008-15 Enclave; 2007-09 Outlook		31871	31872
Fits: DODGE / CHRYSLER 1995-09 Ram Pickups w/tow pkg; 1997-2011 Dakota; 1998-2009 Durango w/tow pkg; 2007-09 Aspen	31707	31864	31687
Fits: DODGE 2013-14 Ram 1500 Pickups w/tow pkg		32079	32080
Fits: DODGE 2010-12 Ram Pickups		31869	31870
Fits: DODGE / JEEP 2011-14 Durango, Grand Cherokee (w/tow)		30012	30011
Fits: FORD 1992-93 F-Series, Bronco	31700	31859	31688
Fits: FORD 2005-07 F-250/F-350; 2005-07 F-450/F-550	31704	31861	31694
Fits: FORD 2009-15 F-150; 2012-14 Flex; 2012-13 MKT	31706	31862	30009
Fits: FORD / LINCOLN 2008-15 F-250/350/450/550; 2009-15 E-150/250/350; 2009-15 E-350/450 RV; 2013 Expedition; 2013-14 Navigator	31698	31863	30013
Fits: FORD / MERCURY / LINCOLN / LAND ROVER 1994-08 F-150; 1994-04 F-250/350; 1997-2012 Expedition; 1994-98 and 2004-08 Van (full size); 2000-05 Excursion; 1996-2003 Windstar; 2006-11 Flex; 2000-15 Explorer; 2002-10 Mountaineer; 1994-96 Bronco; 2005-13 Range Rover; 2005-10 LR3; 2010-11 LR4; 2003-05 Aviator; 2007-08 Mark LT; 2010-11 MKT; 1998-12 Navigator; 2000-14 F53 Motorhome	31701	31860	31689
Fits: HONDA 2006-13 Pilot; 2006-12 Ridgeline	31686	31868	30010
Fits: NISSAN / INFINITI 2004-13 Armada, Titan, Frontier, Pathfinder, QX-56; 2004-08 Xterra; 2012-14 NV Van	31699	31858	31693
Fits: TOYOTA / LEXUS 2003-13 4-Runner; 2002-12 Sequoia; 2003-14 Tundra; 2005-13 Tacoma; 2003-11, 13 Land Cruiser; 2010-13 GX 460; 2004-10 GX 470; 2008-11, 13 LX 570	31713	31867	31697
Husky Square to Flat T-Style Brake Control Adapter		31857	



31701



31704



31708



31689

Note: many Chevy/GMC applications beginning in 2007 do not provide a factory connector and the brake control must be hard wired to the vehicle pigtail located under the dash. This can be accomplished by removing the connector that is furnished with the brake control and butt connecting the 4 bare wires of the Brake Control to the bare wires on the vehicle pigtail.