



Installation Guide

- 1) Find a location which allows speaker to mount flat
- 2) Use template measurements to mark all holes
- 3) Drill starter hole in center of mounting hole
- 4) Cut mounting hole. Use 1/8" drill for screw holes
- 5) Connect pos. speaker wire (+) to pos. tab (marked white or red)
- 6) Connect neg. speaker wire (-) to neg. tab
- 7) Apply bead of non-caustic silicone to rear flange of speaker body (if desired)
- 8) Apply small amount of non-caustic silicone to screw flanges
- 9) Secure speaker with provided hardware (as shown)

**Note: Do Not Allow Silicone to Squeeze
or Make Contact with Rear of Speaker Cone**



WARRANTY POLICY
 PQN Enterprises, Inc. audio products are warranted to be free of manufactured defects in materials and workmanship for a period of 1 (one) year from date of original purchase.