



# Turnoverball™ Model Chart

Complete Kit    Mounting Kit    Center Section

TRUCK YEAR, MAKE AND MODEL

CHEVY/GMC			CHEVY/GMC
GNRK1000	GNRM1000	GNRC800	1988-1998 Chevrolet & GMC 1/2, 3/4, & 1 Ton Long Bed Trucks 1999-2000 Chevrolet & GMC 3/4 & 1 Ton Heavy Duty Long Bed Trucks (Full C-Channel Frame)
GNRK1050	GNRM1050	GNRC950	1988-1998 Chevrolet & GMC 1/2, 3/4, & 1 Ton Short Bed Trucks 1999-2000 Chevrolet & GMC 3/4 & 1 Ton Short Bed Trucks (Full C-Channel Frame)
GNRK1059	GNRM1059	GNRC959	1999-2007 Chevrolet & GMC 1/2 & 3/4 Ton Light Duty All Beds (Tube Frame changing to C-Channel before axle)
GNRK1062	GNRM1062	GNRC962	2001-2007 Chevrolet & GMC 1 Ton Truck (With 2 bed cross members over the axle)
GNRK1057	GNRM1057	GNRC959	2007-2015 Chevrolet & GMC 1/2 Ton SHORT BED ONLY New Boxed Frame
GNRK1007	GNRM1007	GNRC959	2007-2015 Chevrolet & GMC 1/2 Ton LONG BED ONLY New Boxed Frame
GNRK1067	GNRM1067	GNRC959	2001-2010 Chevrolet & GMC 3/4 Ton Heavy Duty Short & Long Bed Trucks 2007-2010 Chevrolet & GMC 1 Ton (New Body) (With 1 bed crossmember over the axle)
GNRK1012	GNRM1012	GNRC912	2011-2015 Chevrolet & GMC 3/4 & 1 Ton HD Long & Short Bed Trucks
GNRK1400			1973-1987 Chevrolet & GMC 1/2, 3/4, & 1 Ton (Requires Drilling)
FORD			FORD
GNRK1100	GNRM1100	GNRC800	1980-1998 Ford 3/4 & 1 Ton WITHOUT Overload Springs
GNRK1110	GNRM1110	GNRC800	1980-1998 Ford 3/4 & 1 Ton WITH Overload Springs ( Requires Drilling 2 Holes)
GNRK1150	GNRM1150	GNRC800	1980-1996 Ford 1/2 Ton Trucks
GNRK1197	GNRM1197	GNRC800	1997-2003 Ford 1/2 & Light Duty 3/4 Ton Trucks, & 2004 Heritage Edition
GNRK1104	GNRM1104	GNRC959	2004-2014 Ford 1/2 Ton Trucks All Beds
GNRK1115	GNRM1115	GNRC900	2015 Ford 1/2 Ton Trucks
GNRK1108	GNRM1108	GNRC800	1999-2010 Ford 3/4 & 1 Ton Super Duty Long and Short Bed Trucks 2008-2010 F450 w/ factory installed bed
GNRK1111	GNRM1111	GNRC800	2011-2015 Ford 3/4 & 1 Ton Super Duty Long and Short Bed Trucks 2011-2015 F450 w/ factory installed bed
DODGE / RAM			DODGE / RAM
GNRK1394	GNRM1394	GNRC900	1994-2001 Dodge 1/2 Ton Trucks All Beds 1994-2002 Dodge 3/4 Ton & 1 Ton Trucks All Beds
GNRK1316	GNRM1316	GNRC900	2002-2008 Dodge 1/2 Ton Long and Short Bed (Except Mega-Cab)
GNRK1308	GNRM1308	GNRC907	2006-2012 Dodge/Ram 1/2, 3/4 & 1 Ton Mega-Cab Trucks 2010-2012 Ram 3/4 & 1 Ton Short and Long Bed Gas Engine Trucks 2013 Ram 3/4 Ton Mega-Cab Trucks 2013 Ram 3/4 Ton Long and Short Bed Gas Engine Trucks
GNRK1309	GNRM1309	GNRC909	2009-2015 Dodge/Ram 1/2 Ton Trucks All Beds (Only GNXA4685 and RVK3500 with special post work with this hitch)
GNRK1313	GNRM1313	GNRC900	2003-2009 Dodge 3/4 & 1 Ton Long and Short Bed Gas or Diesel Trucks 2010-2012 Ram 3/4 & 1 Ton Long and Short Bed Diesel Trucks 2013 Ram 3/4 Ton Long and Short Bed Diesel Trucks
GNRK1314			2013-2015 Ram 1 Ton Trucks
GNRK1384			2014-2015 Ram 3/4 Ton Trucks
GNRK1300			1973-1993 Dodge 1/2, 3/4, & 1 Ton (Requires Drilling)
TOYOTA			TOYOTA
GNRK1251	GNRM1251	GNRC1250	2000-2006 Toyota Tundra All Beds
GNRK1257	GNRM1257	GNRC1256	2007-2015 Toyota Tundra All Beds (Only GNXA4585 and RVK3500 with special post work with this hitch)
NISSAN			NISSAN
GNRK1208	GNRM1208	GNRC1218	2004-2015 Nissan Titan All Beds
FLATBED			FLATBED
GNRK1500			Flatbed Kit 6" x 8" - 1/2" Plate - 1/8" Socket Top Stick Out