

All-in-one Gutter Spouts

with Built-in Extensions

Add a new one or replace the old

Includes: 4 Spouts (2 Left / 2 Right)
Drip rail not included

- For RVs with or without spouts
- Installs in minutes
- Reduces dirt and black streaks
- with built-in extensions



Our return policy is limited to the replacement of original purchase. No other liability, responsibility or warranty is expressed or implied. Including any regarding merchantability or suitability for a particular purpose.



Camco Manufacturing, Inc.
121 Landmark Dr. / Greensboro, NC 27409
1-800-334-2004 / www.camco.net

z885251

Before you start

- Identify left and right hand gutter spouts.
- Familiarize yourself with diagram at right.
 - Left spouts (marked L) – install on driver's side front and passenger side rear gutters.
 - Right spouts (marked R) – install on driver's side rear and passenger side front gutters.
- Drip rail is not included.

Includes:

RV gutter spout pack includes
2 left side spouts marked "L" and
2 right side spouts marked "R"

Tools Needed:

- Utility or putty knife
- 100% Silicone caulk
- Drill and drill bit
- Phillips head screwdriver

1

- Pull vinyl trim insert back until screw shows.
- Remove screw and any existing gutters. Then remove only enough putty around drip rail to install gutter spout.

2

Note: If there is no screw close to the edge of drip rail end, remove only enough putty to slide gutter spout into place, then drill hole through drip rail and spout. (Hole should be centered on spout.)

- Slide gutter spout behind drip rail. If desired, mark and pre-drill gutter spout before replacing screw in existing hole. (Drill size depends on screw size.)
- Apply new putty around gutter spout and drip rail as needed.

3

- Push vinyl trim insert back.
- Repeat Steps 1, 2 and 3 for other sides.