



 **TORKLIFT**
INTERNATIONAL
OVER 35 YEARS OF INNOVATION, QUALITY, SAFETY.
APPPLICATION GUIDES
TORKLIFT.COM • 2015



Ford

Step 1: Select Your Front Tie Downs

Step 2: Optional
Select Your Auxiliary
Power Product
HiddenPower Under
Vehicle Battery Mount

Ford				Step 1: Select Your Front Tie Downs			Step 2: Optional Select Your Auxiliary Power Product HiddenPower Under Vehicle Battery Mount
Year	Model	Cab	Bed	Do running boards extend past the cab?	Standard Front Tie Down	Talon Aluminum Front Tie Down	MFG#
1973-1980	F250, F350	All	8ft				A7703 (1) A7727
2000-2011	Ranger	All	6'	No	F2013		
1981-1997	F350	All	8'	No	F2000 (3)		A7703 (1)
				Yes	F4000 (3,4,5)		A7727
Square body							
1981-1997	F350	All	6.5'	No	F2000 (3)		
				Yes	F4000 (3,4,5)		
Square body							
1981-1997	F250	All	8'	No	F2000 (3)		A7703 (1)
				Yes	F4000 (3,4,5)		A7727
Square body							
1981-1997	F250	All	6.5'	No	F4000 (3,4,5,6)		
				Yes	F4000 (3,4,5,6)		
Square body							
1981-1997	F150	All	All	No	F4000 (3,4,5,6)		
				Yes	F4000 (3,4,5,6)		
Square body							
1997-2003	F150, F250 LD	All	8'	No	F2001		
				Yes	F4001 (4,5)		
Round body							
1997-2003	F150, F250 LD	All	6.5'	No	F2002 (3)		
				Yes	F4002 (3,4,5)		
Round body							
1998-2003	F150	Super Crew	5.5'	No	F2009		
1999-2004	F250, F350	All	8'	No	F2011	F2011A	A7703 (1)
				Yes	F4006 (4,5)		A7727
Super Duty W/ factory bed							
1999-2004	F250, F350	All	6.75'	No	F2007	F2007A	
				Yes	F4007 (4,5)		
Super Duty W/ factory bed							
2004-2005	F150	All	8'	No	F2003		
2004-2005	F150	All	6.5'	No	F2004		
No Step Side bed							
2004-2005	F150	Super Crew	5.5'	No	F2005		
2005-2007	F250, F350	All	8'	No	F2011	F2011A	A7703 (1)
				Yes	F4006 (4,5)		A7727
Super Duty W/ factory bed							

Step 3: Select Your Rear Tie Downs

Step 4: Optional Select Your SuperHitch

Step 5: Select Your Suspension Stabilizer

Rear Tie Downs			SuperHitch		StableLoad	
Standard Rear Tie Down		Talon Aluminum Rear Tie Down	Hitch Type	MFG#	Type	MFG#
Factory	F3004 (15)				Lower	A7311 (2,4)
Aftermarket	R3500 (12)					
Factory	(25)	(25)	Original 20k	F1000 (1B)	Lower	A7311 (2,4)
Superhitch	R3503 (23)	R3503A (23)			Upper	A7200 (3)
Aftermarket	R3501 (12)					
Factory	(25)	(25)	Original 20k	F1000 (1B)	Lower	A7311 (2,4)
Superhitch	R3503 (23)	R3503A (23)			Upper	A7200 (3)
Aftermarket	R3501 (12)					
Factory	(25)	(25)	Original 20k	F1000 (1B)	Lower	A7311 (2,4)
Superhitch	R3503 (23)	R3503A (23)			Upper	A7200 (3)
Aftermarket	R3501 (12)					
Factory	(25)	(25)	Original 20k	F1000 (1B)	Lower	A7311 (2,4)
Superhitch	R3503 (23)	R3503A (23)			Upper	A7200 (3)
Aftermarket	R3501 (12)					
Factory	(25)	(25)			Lower	A7311 (2,4)
Aftermarket	R3501 (12)				Upper	A7200 (3)
Factory	F3001 (15)	F3001A (15)			Lower	A7311 (2,4)
Aftermarket	R3500 (12)				Upper	A7200 (3)
Factory	F3001 (15)	F3001A (15)			Lower	A7311 (2,4)
Aftermarket	R3500 (12)				Upper	A7200 (3)
Factory	F3001 (15)	F3001A (15)			Lower	A7311 (2,4)
Aftermarket	R3500 (12)				Upper	A7200 (3)
Factory	F3001 (15)	F3001A (15)	Original 20k	F1002 (1B, 5)	Lower	A7311 (2,4)
Superhitch	R3503 (23)	R3503A (23)	Magnum 30k	F1002-30 (1C,5)	Upper	A7200 (3)
SH Magnum	R3504	R3504A				
Aftermarket	R3500 (12)					
Factory	F3001 (15)	F3001A (15)	Original 20k	F1002 (1B, 5)	Lower	A7311 (2,4)
Superhitch	R3503 (23)	R3503A (23)	Magnum 30k	F1002-30 (1C,5)	Upper	A7200 (3)
SH Magnum	R3504	R3504A				
Aftermarket	R3500 (12)					
No Hitch	F3003				Lower	A7311 (2,4)
Factory	F3003				Upper	A7200 (3)
Aftermarket	R3500 (12)					
No Hitch	F3003				Lower	A7311 (2,4)
Factory	F3003				Upper	A7200 (3)
Aftermarket	R3500 (12)					
No Hitch	F3003				Lower	A7311 (2,4)
Factory	F3003				Upper	A7200 (3)
Aftermarket	R3500 (12)					
Factory	F3004 (15)	F3001A (15)	Original 20k	F1002 (1B,5)	Lower	A7311 (2,4)
Superhitch	R3503 (23)	R3503A (23)	Magnum 30k	F1002-30 (1C,5)	Upper	A7200 (3)
SH Magnum	R3504	R3504A				
Aftermarket	R3500 (12)					

Ford

Step 1: Select Your Front Tie Downs

Step 2: Optional Select Your Auxiliary Power Product HiddenPower Under Vehicle Battery Mount

				Front Tie Downs			
Year	Model	Cab	Bed	Do running boards extend past the cab?	Standard Front Tie Down	Talon Aluminum Front Tie Down	MFG#
2005-2007	F250, F350	All	6.75'	No	F2007	F2007A	
				Yes	F4007 (4,5)		
Super Duty W/ factory bed							
2006-2007	F150	Super Crew	5.5'	No	F2010		
2006-2008	F150	All	8'	No	F2003		
2006-2008	F150	All	6.5'	No	F2014	F2014A	
No Step Side bed							
2008-2010	F250, F350, F450	All	8'	No	F2011	F2011A	A7728
Super Duty W/ factory bed							
2008-2010	F250, F350	All	6.75'	No	F2012 (2)	F2012A (2)	
Super Duty W/ factory bed							
2008	F150	Super Crew	5.5'	No	F2017		
2000-2015	F350, F450, F550	All	N/A	No	F2008 (22)		
					(2005-2015 Only)		
Cab & Chassis (34" wide Frame)							
2009-2014	F150	All	6.5'	No	F2014	F2014A	A7726
							(2010-2014) Extended and Crew Cab Only
2009-2014	F150	All	8'	No	F2015		

Step 3: Select Your Rear Tie Downs

Step 4: Optional Select Your SuperHitch

Step 5: Select Your Suspension Stabilizer

Rear Tie Downs			SuperHitch		StableLoad	
Standard Rear Tie Down		Talon Aluminum Rear Tie Down	Hitch Type	MFG#	Type	MFG#
Factory	F3004 (15)	F3001A (15)	Original 20k	F1002 (1B, 5)	Lower	A7311 (2,4)
Superhitch	R3503 (23)	R3503A (23)	Magnum 30k	F1002-30 (1C,5)	Upper	A7200 (3)
SH Magnum	R3504	R3504A				
Aftermarket	R3500 (12)					
No Hitch	F3005	F3005A			Lower	A7311 (2,4)
Factory	F3005	F3005A			Upper	A7200 (3)
Aftermarket	R3500 (12)					
No Hitch	F3005	F3005A			Lower	A7311 (2,4)
Factory	F3005	F3005A			Upper	A7200 (3)
Aftermarket	R3500 (12)					
No Hitch	F3005	F3005A			Lower	A7311 (2,4)
Factory	F3005	F3005A			Upper	A7200 (3)
Aftermarket	R3500 (12)					
Factory	F3004 (5)	F3001A (15)	Original 20k	F1002 (1B, 5)	08-09 Lower	A7311 (2,4)
Superhitch	R3503 (23)	R3503A (23)	Magnum 30k	F1002-30 (1C, 5)	2010 Lower	A7310 (1,4)
SH Magnum	R3504	R3504A			Upper	A7200 (3)
Aftermarket	R3500 (12)					
Factory	F3004 (5)	F3001A (15)	Original 20k	F1002 (1B, 5)	08-09 Lower	A7311 (2,4)
Superhitch	R3503 (23)	R3503A (23)	Magnum 30k	F1002-30 (1C, 5)	2010 Lower	A7310 (1,4)
SH Magnum	R3504	R3504A			Upper	A7200 (3)
Aftermarket	R3500 (12)					
No Hitch	F3005	F3005A			Lower	A7311 (2,4)
Factory	F3005	F3005A			Upper	A7200 (3)
Aftermarket	R3500 (12)					
Superhitch	R3503 (23)	R3503A (23)	Original 20k	F1003 (1B, 5)	Upper	A7200 (3)
SH Magnum	R3504	R3504A	Magnum 30k	F1003-30 (1C, 5)		
Aftermarket	R3500 (12)					
No Hitch	F3005	F3005A	Hero 15k	F1005H (1A,1H,2)	2009 Lower	A7311 (2,4)
Factory	F3005	F3005A	Only works with factory hitch rated to 10,500 lbs		2010 Lower	A7310 (2,4)
Hero	R3508	R3508A			Upper	A7200 (3)
Aftermarket	R3500 (12)					
No Hitch	F3005	F3005A	Hero 15k	F1005H (1A,1H,2)	2009 Lower	A7311 (2,4)
Factory	F3005	F3005A	Only works with factory hitch rated to 10,500 lbs		2010 Lower	A7310 (2,4)
Hero	R3508	R3508A			Upper	A7200 (3)
Aftermarket	R3500 (12)					

Ford

Step 1: Select Your Front Tie Downs

Step 2: Optional Select Your Auxiliary Power Product HiddenPower Under Vehicle Battery Mount

Ford				Front Tie Downs			Step 2: Optional Select Your Auxiliary Power Product HiddenPower Under Vehicle Battery Mount
Year	Model	Cab	Bed	Do running boards extend past the cab?	Standard Front Tie Down	Talon Aluminum Front Tie Down	MFG#
2009-2014	F150	Super Crew	5.5'	No	F2017		
2011-2015	F250, F350	All	6.75'	No	F2012	F2012A	
	Super Duty W/ factory bed						
2011-2015	F250, F350, F450	All	8'	No	F2016 (27)	F2016A (27)	A7728
	Super Duty W/ factory bed						
2015	F150		6.5'	No	F2018	F2018A	
	Super Cab, Super Crew						
2015	F150	All	5.5'	No	N/A		
2015	F150	Regular	8'	No	N/A		
1999-2005	Excursion						
2001-2008	E150	Van					
2005-2011	E250, E350	Van					A7729
2012-2013	E250, E350	Van					A7729
All	E450 Frame	RV					A7740 (2)
2016	F250, F350	Super Crew	6.75'	No	F2012	F2012A	
	Super Duty W/ factory bed						
2016	F250, F350	Super Crew	8'	No	F2016 (27)	F2016A (27)	A7728
	Super Duty W/ factory bed						
2016	F250	Super Cab	8'	No	F2016 (27)	F2016A (27)	A7728
	Super Duty W/ factory bed						
2016	F550	Regular	N/A				
	Cab & Chassis (34" wide frame)						

Step 3: Select Your Rear Tie Downs

Step 4: Optional Select Your SuperHitch

Step 5: Select Your Suspension Stabilizer

Rear Tie Downs			SuperHitch		StableLoad	
Standard Rear Tie Down		Talon Aluminum Rear Tie Down	Hitch Type	MFG#	Type	MFG#
No Hitch	F3005	F3005A	Hero 15k	F1005H (1A,1H,2)	2009 Lower	A7311 (2,4)
Factory	F3005	F3005A	Only works with factory hitch rated to 10,500 lbs		2010 Lower	A7310 (2,4)
Hero	R3508	R3508A			Upper	A7200 (3)
Aftermarket	R3500 (12)					
Factory	F3006 (15)	F3001A (15)	Original 20k	F1002	Lower	A7310 (2,4)
Superhitch	R3503 (23)	R3503A (23)	Magnum 30k	F1002-30(1C,5)	Upper	A7200 (3)
SH Magnum	R3504	R3504A				
Aftermarket	R3500 (12)					
Factory	F3006 (15)	F3001A (15)	Original 20k	F1002 (1B,5)	Lower	A7310 (2,4)
Superhitch	R3503 (23)	R3503A (23)	Magnum 30k	F1002-30 (1C,5)	Upper	A7200 (3)
SH Magnum	R3504	R3504A				
Aftermarket	R3500 (12)					
No Hitch	F3007	F3007A				
Factory	F3007	F3007A				
No Hitch	F3007	F3007A				
Factory	F3007	F3007A				
No Hitch	F3007	F3007A				
Factory	F3007	F3007A				
			Original 20k	F1006 (1B)	Lower	A7310 (2,4)
					Lower	A7311 (2,4)
					Lower	A7311 (2,4)
					Lower	A7310 (2,4)
Factory	F3006 (15)	F3001A (15)	Original 20K	F1002 (1B,5)	Lower	A7310 (2,4)
SuperHitch	R3503 (23)	R3503A (23)	Magnum 30K	F1002-30 (1C,5)	Upper	A7200 (3)
SuperHitch Mgnum	R3504	R3504A				
Aftermarket	R3500 (12)					
Factory	F3006 (15)	F3001A (15)	Original 20K	F1002 (1B, 5)	Lower	A7310 (2,4)
SuperHitch	R3503 (23)	R3503A (23)	Magnum 30K	F1002-30 (1C, 5)	Upper	A7200 (3)
SuperHitch Mgnum	R3504	R3504A				
Aftermarket	R3500 (12)					
Factory	F3006 (15)	F3001A (15)	Original 20K	F1002 (1B, 5)	Lower	A7310 (2,4)
SuperHitch	R3503 (23)	R3503A (23)	Magnum 30K	F1002-30 (1C, 5)	Upper	A7200 (3)
SuperHitch Mgnum	R3504	R3504A				
Aftermarket	R3500 (12)					
SuperHitch	R3503 (23)	R3503A (23)	Original 20K	F1003 (1B, 5)	Upper	A7200 (3)
SuperHitch Mgnum	R3504	R3504A	Magnum 30K	F1003-30 (1C,5)		
Aftermarket	R3500 (12)					

For footnotes and turnbuckles, see last page of app guide.

Dodge

Step 1: Select Your Front Tie Downs

Step 2: Optional Select Your Auxiliary Power Product HiddenPower Under Vehicle Battery Mount

Dodge				Step 1: Select Your Front Tie Downs			Step 2: Optional Select Your Auxiliary Power Product HiddenPower Under Vehicle Battery Mount
Year	Model	Cab	Bed	Do running boards extend past the cab?	Standard Front Tie Down	Talon Aluminum Front Tie Down	MFG#
All	Sprinter	Van	N/A				
1987-1996	Dakota	All	All				
1980-1988	D250, D350	All	8ft				
1989-1993	D250, D350	All	8ft	No	F4000 (3,4,5,6)		
				Yes	F4000 (3,4,5,6)		
1989-1993	D150	All	8ft	No	F4000 (3,4,5,6)		
				Yes	F4000 (3,4,5,6)		
1994-2001	1500	All	8ft	No	D2100 (3)		A7742
				Yes	D4100 (3,4,5)		(NO Regular Cab)
1994-2001	1500	All	6.5ft	No	D2110		
				Yes	D4104 (3,4,5)		
1994-2002	2500, 3500	All	8ft	No	D2100 (3)		A7742
				Yes	D4100 (3,4,5)		(No Regular Cab)
1994-2002	2500, 3500	All	6.5ft	No	D2110		
				Yes	D4104		
1997-2004	Dakota	All	6.5ft	No	D2104		
2002-2003	1500	All	8ft	No	D2107 (3)		
2002-2003	1500	All	6.5ft	No	D2106		
				Two Wheel Drive Only			
2002-2003	1500	All	6.5ft	No	D2105		
				Four Wheel Drive Only			
2003-2008	2500, 3500 HD	Quad	6.5ft	No	D2103 (3)		
				Two Wheel Drive Only			
2003-2009	2500, 3500 HD	All	6.5ft	No	D2102		A7740
				Yes	D4102 (2,3,4,5)		
				Four Wheel Drive Only			
2003-2009	2500, 3500 HD	All	8ft	No	D2101	D2101A	A7740
				Yes	D4101 (4,5)		
2004-2008	1500	All	8ft	No	D2107 (3)		
2004-2008	1500	Reg, Quad	6.5ft	No	D2106		
				Two Wheel Drive Only			

Step 3: Select Your Rear Tie Downs

Step 4: Optional Select Your SuperHitch

Step 5: Select Your Suspension Stabilizer

Rear Tie Downs			SuperHitch		StableLoad	
Standard Rear Tie Down		Talon Aluminum Rear Tie Down	Hitch Type	MFG#	Type	MFG#
					Lower	A7311 (2,4)
					Lower	A7311 (2,4)
			Original 20K	F1000 (1B,1,3)		
Superhitch	R3503 (23)	R3503A (23)	Original 20K	F1000 (1B,1,3)		
Aftermarket	R3501 (12)					
Aftermarket	R3501 (12)					
Factory	D3101 (15)				Lower	A7311 (2,4)
Aftermarket	R3500 (12)					
Factory	D3101 (15)				Lower	A7311 (2,4)
Aftermarket	R3500 (12)					
Factory	D3101 (15)		Original 20K	D1100 (1B,3)	Upper	A7200 (3)
Superhitch	R3503 (23)	R3503A (23)			Lower	A7311 (2,4)
Aftermarket	R3500 (12)					
Factory	D3101 (15)		Original 20K	D1100 (1B,1,3)	Lower	A7311 (2,4)
Superhitch	R3503 (23)	R3503A (3)				
Aftermarket	R3500 (12)					
Factory	D3105 (15)				Lower	A7311 (2,4)
Aftermarket	R3500 (12)					
Factory	D3103				Lower	A7311 (2,4)
Aftermarket	R3500 (12)					
Factory	D3103				Lower	A7311 (2,4)
Aftermarket	R3500 (12)					
Factory	D3103				Lower	A7311 (2,4)
Aftermarket	R3500 (12)					
Factory	D3103				Lower	A7311 (2,4)
Aftermarket	R3500 (12)					
No Hitch	D3109 (11,14,20)	D3109A (11,14,20)	Original 20K	D1101 (1B,2)	Upper	A7200 (3)
Factory	D3109 (11,14,20)	D3109A (11,14,20)	(For Bolted On Factory Receiver)		Lower	A7311 (2,4)
Superhitch	R3503 (14,20,23)		Original 20K	D1102 (1B,1,3)		
SH Magnum	R3503 (14,20,23)		Magnum 30K	D1102-30 (1C,1,3)		
Aftermarket	R3500 (14,12)		(For Welded On Factory Receiver)			
No Hitch	D3109 (11,14,20)	D3109A (11,14,20)	Original 20K	D1101 (1B,2)	Upper	A7200 (3)
Factory	D3109 (11,14,20)	D3109A (11,14,20)	(For Bolted On Factory Receiver)		Lower	A7311 (2,4)
Superhitch	R3503 (14,20,23)		Original 20K	D1102 (1B,1,3)		
SH Magnum	R3503 (14,20,23)		Magnum 30K	D1102-30 (1C,1,3)		
Aftermarket	R3500 (14,12)		(For Welded On Factory Receiver)			
No Hitch	D3109 (11,14,20)	D3109A (11,14,20)	Original 20K	D1101 (1B,2)	Upper	A7200 (3)
Factory	D3109 (11,14,20)	D3109A (11,14,20)	(For Bolted On Factory Receiver)		Lower	A7311 (2,4)
Superhitch	R3503 (14,20,23)		Original 20K	D1102 (1B,1,3)		
SH Magnum	R3503 (14,20,23)		Magnum 30K	D1102-30 (1C,1,3)		
Aftermarket	R3500 (14,12)		(For Welded On Factory Receiver)			
No Hitch	D3109 (11,14,20)	D3109A (11,14,20)			Lower	A7311 (2,4)
Factory	D3109 (11,14,20)	D3109A (11,14,20)				
Aftermarket	R3500 (12)					
No Hitch	D3109 (11,14,20)	D3109A (11,14,20)			Lower	A7311 (2,4)
Factory	D3109 (11,14,20)	D3109A (11,14,20)				
Aftermarket	R3500 (12)					

Dodge

Step 1: Select Your Front Tie Downs

Step 2: Optional Select Your Auxiliary Power Product HiddenPower Under Vehicle Battery Mount

Year	Model	Cab	Bed	Do running boards extend past the cab?	Front Tie Downs		MFG#
					Standard Front Tie Down	Talon Aluminum Front Tie Down	
2004-2008	1500	Reg. Quad	6.5ft	No	D2105		
	Four Wheel Drive Only						
2005	Dakota	Quad	5.5ft	No	D2114		
2005	Dakota	Ext	6.5ft	No	D2109		
2006-2010	Dakota	Ext / Club	6.5ft	No	D2109		
2006-2008	1500	Mega	6.5ft	No	D2111		
	Two Wheel Drive Only						
2006-2008	1500	Mega	6.5ft	No	D2102		
	Four Wheel Drive Only						
2006-2009	2500, 3500	Mega	6.5ft	No	D2111		A7740
	Two Wheel Drive Only						
2007-2015	3500, 4500, 5500	All	N/A	No	D2112		
		Cab & Chassis					
2009-2012	1500	Quad	6.5ft	No	D2121		
	Four Wheel Drive Only (No Laramie Edition)						
2010-2012	2500, 3500	All	8ft	No	D2115	D2115A	A7740
				Yes	D4101 (4,5)		(Crew Cab ONLY)
2010-2012	2500, 3500	All	6.5ft	No	D2119		A7740
				Yes	D4106 (4,16)		(Mega Cab Only)
Four Wheel Drive Only (Single Rear Wheel)							
2010-2012	3500	All	6.5ft	No	D2120		A7740
				Yes	D4106 (4,16)		(Mega Cab Only)
Dual Rear Wheel							
2013	2500	All	8ft	No	D2115		A7740
				Yes	D4105 (4,5)		(Crew Cab Only)

Step 3: Select Your Rear Tie Downs

Step 4: Optional Select Your SuperHitch

Step 5: Select Your Suspension Stabilizer

Rear Tie Downs			SuperHitch		StableLoad	
Standard Rear Tie Down	Talon Aluminum Rear Tie Down	Hitch Type	MFG#	Type	MFG#	
No Hitch	D3109 (11,14,20)	D3109A (11,14,20)			Lower	A7311 (2,4)
Factory	D3109 (11,14,20)	D3109A (11,14,20)				
Aftermarket	R3500 (12)					
Aftermarket	R3500 (12)				Lower	A7311 (2,4)
Aftermarket	R3500 (12)				Lower	A7311 (2,4)
Factory	D3106				Lower	A7311 (2,4)
Aftermarket	R3500 (12)					
No Hitch	D3109 (11,14,20)	D3109A (11,14,20)			Lower	A7311 (2,4)
Factory	D3109 (11,14,20)	D3109A (11,14,20)				
Aftermarket	R3500 (12)					
No Hitch	D3109 (11,14,20)	D3109A (11,14,20)			Lower	A7311 (2,4)
Factory	D3109 (11,14,20)	D3109A (11,14,20)				
Aftermarket	R3500 (12)					
No Hitch	D3109 (11,14,20)	D3109A (11,14,20)	Original 20K	D1101 (1B,2)	Upper	A7200 (3)
Factory	D3109 (11,14,20)	D3109A (11,14,20)	(For Bolted On Factory Receiver)		Lower	A7311 (2,4)
Superhitch	R3503 (14,20,23)		Original 20K	D1102 (1B,2,3)		
SH Magnum	R3503 (14,20,23)		Magnum 30K	D1102-30 (1C,3)		
Aftermarket	R3500 (12,14)		(For Welded On Factory Receiver)			
SH Magnum	R3504 (14,20)	R3504A (14,20)	Magnum 30K	D1103-30 (1C,2,3)	Upper	A7200 (3)
Aftermarket	R3500 (12)				(4500 & 5500 ONLY)	
No Hitch	D3107 (15,26)		Hero	D1106H (1A,2H)		
Factory	D3107 (15,26)		With Factory Welded Factory Hitch			
SH Hero	D3107 (15,26)					
Aftermarket	R3500 (12)					
No Hitch	D3109 (11,14,20)	D3109A (11,14,20)	Original 20K	D1101 (1B,2)	Upper	A7200 (3)
Factory	D3109 (11,14,20)	D3109A (11,14,20)	(For Bolted On Factory Receiver)		Lower	A7311 (2,4)
Superhitch	R3505 (14,20,23)	R3503A (14,20,23)	Original 20K	D1102 (1B,2,3)		
SH Magnum	R3505 (14,20,23)	R3503A (14,20,23)	Magnum 30K	D1102-30 (1C,3)		
Aftermarket	R3500 (12,14)		(For Welded On Factory Receiver)			
No Hitch	D3109 (11,14,20)	D3109A (11,14,20)	Original 20K	D1101 (1B,2)	Upper	A7200 (3)
Factory	D3109 (11,14,20)	D3109A (11,14,20)	(For Bolted On Factory Receiver)		Lower	A7311 (2,4)
Superhitch	R3505 (14,20,23)	R3503A (14,20,23)	Original 20K	D1102 (1B,2,3)		
SH Magnum	R3505 (14,20,23)	R3503A (14,20,23)	Magnum 30K	D1102-30 (1C,3)		
Aftermarket	R3500 (12,14)		(For Welded On Factory Receiver)			
No Hitch	D3109 (11,14,20)	D3109A (11,14,20)	Original 20K	D1101 (1B,2)	Upper	A7200 (3)
Factory	D3109 (11,14,20)	D3109A (11,14,20)	(For Bolted On Factory Receiver)		Lower	A7311 (2,4)
Superhitch	R3505 (14,20,23)	R3503A (14,20,23)	Original 20K	D1102 (1B,2,3)		
SH Magnum	R3505 (14,20,23)	R3503A (14,20,23)	Magnum 30K	D1102-30 (1C,3)		
Aftermarket	R3500 (12,14)		(For Welded On Factory Receiver)			
No Hitch	D3109 (11,14,20)	D3109A (11,14,20)	Original 20K	D1104 (1B,2,3)	Upper	A7200 (3)
Factory	D3109 (11,14,20)	D3109A (11,14,20)	Magnum 30K	D1104-30 (1C,2,3)	Lower	A7311 (2,4)
Superhitch	R3507 (14,20,21)	R3507A (14,20,21)	(With Factory Welded Hitch)			
SH Magnum	R3507 (14,20,21)	R3507A (14,20,21)				
Aftermarket	R3500 (12)					

Dodge

Step 1: Select Your Front Tie Downs

Step 2: Optional Select Your Auxiliary Power Product HiddenPower Under Vehicle Battery Mount

Year	Model	Cab	Bed	Front Tie Downs			MFG#
				Do running boards extend past the cab?	Standard Front Tie Down	Talon Aluminum Front Tie Down	
2013	2500	All	6.5ft	No	D2119		
				Yes	D4106 (4,16)		
2013	3500	Crew	6.5ft	No	D2120		
				Yes	D4106 (4,16)		
Dual Rear Wheel							
2013-2015	1500	All	6.5ft	No	D2121		
2013-2015	3500	Crew, Mega	6.5ft	No	D2123	D2123A	
				Yes	D2128	D2128A	
Single Rear wheel							
2013-2015	3500	Mega	6.5ft	No	D2125	D2125A	
				Yes			
Dual Rear Wheel							
2013-2016	3500	Crew	8ft	No	D2124 (31)	D2124A (31)	A7740
				Yes	D2127 (29)	D2127A (29)	
2014-2015	1500	Reg	8ft				
2014-2015	1500	Crew	5.5ft				
2014	2500	Reg	8ft	No running boards	D2126 (28)	D2126A (28)	
				Factory running boards	D2127 (29)	D2127A (29)	
Gas Engine							

Step 3: Select Your Rear Tie Downs

Step 4: Optional Select Your SuperHitch

Step 5: Select Your Suspension Stabilizer

Rear Tie Downs			SuperHitch		StableLoad	
Standard Rear Tie Down		Talon Aluminum Rear Tie Down	Hitch Type	MFG#	Type	MFG#
No Hitch	D3109 (11,14,20)	D3109A (11,14,20)	Original 20K	D1104 (1B,2,3)	Upper	A7200 (3)
Factory	D3109 (11,14,20)	D3109A (11,14,20)	Magnum 30K	D1104-30 (1C,2,3)	Lower	A7311 (2,4)
Superhitch	R3507 (14,20,21)	R3507A (14,20,21)	(With Factory Welded Hitch)			
SH Magnum	R3507 (14,20,21)	R3507A (14,20,21)				
Aftermarket	R3500 (12)					
No Hitch	D3109 (11,14,20)	D3109A (11,14,20)	Original 20K	D1104 (1B,2,3)	Lower	A7311 (2,4)
Factory	D3109 (11,14,20)	D3109A (11,14,20)	Magnum 30K	D1104-30 (1C,2,3)	Upper	A7200 (3)
Superhitch	R3507 (14,20)	R3507A (14,20)	(With Factory Welded Hitch)			
SH Magnum	R3507 (14,20)	R3507A (14,20)				
Aftermarket	R3500 (14,12)					
No Hitch	D3107		Hero	D1106H (1A,2H)		
Factory	D3107		(With Factory Welded Hitch)			
Hero	D3107					
Aftermarket	R3500 (12)					
No Hitch	D3109 (11,14,20)	D3109A (11,14,20)	Original 20K	D1104 (1B,2,3)	Lower	A7311 (2,4)
Factory	D3109 (11,14,20)	D3109A (11,14,20)	Magnum 30K	D1104-30 (1C,2,3)	Upper	A7200 (3)
Superhitch	R3507 (14,20)	R3507A (14,20)	(With Factory Welded Hitch)			
SH Magnum	R3507 (14,20)	R3507A (14,20)				
Aftermarket	R3500 (12)					
No Hitch	D3109 (11,14,20)	D3109A (11,14,20)	Original 20K	D1104 (1B,2,3)	Lower	A7311 (2,4)
Factory	D3109 (11,14,20)	D3109A (11,14,20)	Magnum 30K	D1104-30 (1C,2,3)	Upper	A7200 (3)
Superhitch	R3507 (14,20)	R3507A (14,20)	(With Factory Welded Hitch)			
SH Magnum	R3507 (14,20)	R3507A (14,20)				
Aftermarket	R3500 (12)					
No Hitch	D3109 (11,14,20)	D3109A (11,14,20)	Original 20K	D1104 (1B,2,3)	Lower	A7311 (2,4,8)
Factory	D3109 (11,14,20)	D3109A (11,14,20)	Magnum 30K	D1104-30 (1C,2,3)	Upper	A7200 (3,8)
Superhitch	R3507 (14,20)	R3507A (14,20)	(With Factory Welded Hitch)			
SH Magnum	R3507 (14,20)	R3507A (14,20)				
Aftermarket	R3500 (12,14)					
No Hitch	D3107					
Factory	D3107					
Aftermarket	R3500 (12)					
No Hitch	D3107		Hero	D1106H (1A,2H)		
Factory	D3107		(With Factory Welded Hitch)			
Hero	D3107					
Aftermarket	R3500 (12)					
No Hitch	D3109 (11,14,20)	D3109A (11,14,20)	Original 20K	D1107 (1B,2,3)		
Factory	D3109 (11,14,20)	D3109A (11,14,20)	Magnum 30K	D1107-30 (1C,2,3)		
Superhitch	R3507 (14,20)	R3507A (14,20)	(With Factory Welded Hitch)			
SH Magnum	R3507 (14,20)	R3507A (14,20)				
Aftermarket	R3500 (12)					

For footnotes and turnbuckles, see last page of app guide.

Dodge

Step 1: Select Your Front Tie Downs

Step 2: Optional Select Your Auxiliary Power Product HiddenPower Under Vehicle Battery Mount

Dodge				Front Tie Downs			Step 2: Optional Select Your Auxiliary Power Product HiddenPower Under Vehicle Battery Mount
Year	Model	Cab	Bed	Do running boards extend past the cab?	Standard Front Tie Down	Talon Aluminum Front Tie Down	MFG#
2014-2015	2500	Crew, Mega	6.5ft	No running boards	D2126 (28)	D2126A (28)	
				Factory running boards	D2127 (29)	D2127A (29)	
2014-2015	2500	Crew	8ft	No running boards	D2126 (28)	D2126A (28)	A7740
				Factory running boards	D2127 (29)	D2127A (29)	
2015	3500	Crew, Mega	6.5ft	No	D2123	D2123A	
				Yes	D2128	D2128A	
Single Rear Wheel							
2015	3500	Reg	8ft	No (Diesel Engine)	D2129 (30)		A7740
				No (Gas Engine)	D2124 (31)	D2124A (31)	
2014-2015	4500	All	N/A				
	With Factory Bed						
2014-2015	4500, 5500	All	N/A				
	Cab and Chassis						

Step 3: Select Your Rear Tie Downs

Step 4: Optional Select Your SuperHitch

Step 5: Select Your Suspension Stabilizer

Rear Tie Downs			SuperHitch		StableLoad	
Standard Rear Tie Down		Talon Aluminum Rear Tie Down	Hitch Type	MFG#	Type	MFG#
No Hitch	D3109 (11,14,20)	D3109A (11,14,20)	Original 20K	D1107 (1B,2,3)		
Factory	D3109 (11,14,20)	D3109A (11,14,20)	Magnum 30K	D1107-30 (1C,2,3)		
Superhitch	R3507 (14,20)	R3507A (14,20)	(With Factory Welded Hitch)			
SH Magnum	R3507 (14,20)	R3507A (14,20)				
Aftermarket	R3500 (12)					
No Hitch	D3109 (11,14,20)	D3109A (11,14,20)	Original	D1107 (1B,2,3)		
Factory	D3109 (11,14,20)	D3109A (11,14,20)	Magnum 30K	D1107-30 (1C,2,3)		
Superhitch	R3507 (14,20)	R3507A (14,20)	(With Factory Welded Hitch)			
SH Magnum	R3507 (14,20)	R3507A (14,20)				
Aftermarket	R3500 (12)					
No Hitch	D3109 (11,14,20)	D3109A (11,14,20)	Original 20K	D1104 (1B,2,3)	Lower	A7311 (2,4)
Factory	D3109 (11,14,20)	D3109A (11,14,20)	Magnum 30K	D1104-30 (1C,2,3)	Upper	A7200 (3)
Superhitch	R3507 (14,20)	R3507A (14,20)	(With Factory Welded Hitch)			
SH Magnum	R3507 (14,20)	R3507A (14,20)				
Aftermarket	R3500 (12)					
No Hitch	D3109 (11,14,20)	D3109A (11,14,20)	Original 20K	D1104 (1B,2,3)	Lower	A7311 (2,4)
Factory	D3109 (11,14,20)	D3109A (11,14,20)	Magnum 30K	D1104-30 (1C,2,3)	Upper	A7200 (3)
Superhitch	R3507 (14,20)	R3507A (14,20)	(With Factory Welded Hitch)			
SH Magnum	R3507 (14,20)	R3507A (14,20)				
Aftermarket	R3500 (12)					
					Lower	A7311 (2,4)
					Upper	A7200 (3)
			Magnum 30K	D1103-30 (1C,2,3)	Upper	A7200 (3)

For footnotes and turnbuckles, see last page of app guide.

Chevrolet

Step 1: Select Your Front Tie Downs

Step 2: Optional Select Your Auxiliary Power Product HiddenPower Under Vehicle Battery Mount

Chevrolet				Front Tie Downs			HiddenPower Under Vehicle Battery Mount
Year	Model	Cab	Bed	Do running boards extend past the cab?	Standard Front Tie Down	Talon Aluminum Front Tie Down	MFG#
1982-1987	2500	All	8ft				
1982-1990	3500	All	8ft				
1988-1994	2500	All	8ft	No	C2201 (3)		
				Yes	C4201 (3,4,5)		
1988-1994	1500	All	8ft	No	C2201 (3)		
				Yes	C4201 (3,4,5)		
1988-1994	2500	All	6.5ft	No	C4201 (3,4,5,6)		
				Yes	C4201 (3,4,5)		
1988-1994	1500	All	6.5ft	No	C4201 (3,4,5,6)		
				Yes	C4201 (3,4,5)		
1991-1994	3500	All	8ft	No	C2201 (3)		
				Yes	C4201 (3,4,5)		
1995-2000	2500	All	8ft	No	C2201 (3)		
				Yes	C4201 (3,4,5)		
C/K Body Style							
1995-2000	1500	All	8ft	No	C2201 (3)		
				Yes	C4201 (3,4,5)		
C/K Body Style							
1995-2000	2500	All	6.5ft	No	C4201 (3,4,5,6)		
				Yes	C4201 (3,4,5)		
C/K Body Style							
1995-2000	1500	All	6.5ft	No	C4201 (3,4,5,6)		
				Yes	C4201 (3,4,5)		
C/K Body Style							
1995-2000	3500	All	8ft	No	C2201 (3)		
				Yes	C4201 (3,4,5)		
C/K Body Style							
2000-2013	Suburban 2500, Yukon XL						
ALL	Express, Savana(2500, 3500)						
1999-2007	1500, 2500	Ext, Regular	6.5	No	C2202 (3,10)		
				Yes	C4203 (3,4,5)		
Silverado 5.5" Frame 2007 Is Classic Model							
1999-2007	1500, 2500	Regular, Extended	8	No	C2202 (3,10)		
				Yes	C4203 (3,4,5)		
Silverado 5.5" Frame 2007 Is Classic Model							
2004-2007	1500	Crew	5.5	No	C2211		
				Yes			
Silverado 5.5" Frame 2007 Is Classic Model							
1999-2007	1500HD, 2500HD	All	6.5'	No	C2205 (10)	C2205A (10)	A7730
				Yes	C4203 (3,4,5)		
SilveradoHD 8" Frame 2007 Is Classic Model							2001-2007 2500HD Crew Cab Only

Step 3: Select Your Rear Tie Downs

Step 4: Optional Select Your SuperHitch

Step 5: Select Your Suspension Stabilizer

Rear Tie Downs			SuperHitch		StableLoad	
Standard Rear Tie Down		Talon Aluminum Rear Tie Down	Hitch Type	MFG#	Type	MFG#
			Original 20k	C1200 (1B,1)		
			Original 20k	C1200 (1B,1)		
Factory	C3201 (15)		Original 20k	C1201 (1B,1)	Lower	A7310 (1,4)
Superhitch	R3503 (23)	R3503A (23)				
Aftermarket	R3500 (12)					
Factory	C3201 (15)				Lower	A7310 (1,4)
Aftermarket	R3500 (12)					
Factory	C3201 (15)		Original 20k	C1201 (1B,1)	Lower	A7310 (1,4)
Superhitch	R3503 (23)	R3503A (23)				
Aftermarket	R3500 (12)					
Factory	C3201 (15)				Lower	A7310 (1,4)
Aftermarket	R3500 (12)					
Factory	C3201 (15)		Original 20k	C1201 (1B,1)	Lower	A7310 (1,4,5)
Superhitch	R3503 (23)	R3503A (23)				
Aftermarket	R3500 (12)					
Factory	C3202 (15)		Original 20k	C1201 (1B,1)	Lower	A7310 (1,4)
Superhitch	R3503 (23)	R3503A (23)				
Aftermarket	R3500 (12)					
Factory	C3202 (15)				Lower	A7310 (1,4)
Aftermarket	R3500 (12)					
Factory	C3202 (15)		Original 20k	C1201 (1B,1)	Lower	A7310 (1,4)
Superhitch	R3503 (23)	R3503A (23)				
Aftermarket	R3500 (12)					
Factory	C3202 (15)				Lower	A7310 (1,4)
Aftermarket	R3500 (12)					
Factory	C3202 (15)		Original 20k	C1201 (1B,1)	Lower	A7310 (1,4,5)
Superhitch	R3503 (23)	R3503A (23)				
Aftermarket	R3500 (12)					
					Lower	A7310 (1,4)
					Lower	A7310 (1,4,5)
No Hitch	C3203				Lower	A7310 (1,4)
Factory	C3203					
Aftermarket	R3500					
No Hitch	C3204		Original 20k	C1202 (1B)	Lower	A7310 (1,4)
Factory	C3204					
Superhitch	R3503 (23)	R3503A (23)		1999-2000 2500 Only		
Aftermarket	R3500 (12)					
No Hitch	C3203				Lower	A7310 (1,4)
Factory	C3203					
Aftermarket	R3500 (12)					
No Hitch	C3205	C3205A	Original 20k	C1204 (1B,4)	Lower	A7310 (1,4)
Factory	C3205	C3205A	Magnum 30k	C1204-30 (1C,4)		
Superhitch	R3503 (23)	R3503A (23)				
SH Magnum	R3504	R3504A		2001-2007 2500HD Only		
Aftermarket	R3500 (12)					

Chevrolet

Step 1: Select Your Front Tie Downs

Step 2: Optional Select Your Auxiliary Power Product HiddenPower Under Vehicle Battery Mount

Chevrolet				Front Tie Downs			Step 2: Optional Select Your Auxiliary Power Product HiddenPower Under Vehicle Battery Mount
Year	Model	Cab	Bed	Do running boards extend past the cab?	Standard Front Tie Down	Talon Aluminum Front Tie Down	MFG#
2001-2007	2500HD, 3500	All	8	No	C2204 (10)	C2204A (10)	A7730
				Yes	C4203 (3,4,5)		Extended and Crew Cab Only
	Silverado HD 8" Frame 2007 Is Classic Model						
2007-2010	2500,3500	All	6.5ft	No	C2205	C2205A	A7730
				Yes	C4203 (3,4,5)		Crew Cab Only
	New Body						
2007-2010	2500,3500	All	8ft	No	C2204	C2204A	A7730
				Yes	C4203 (3,4,5)		Extended & Crew Cab Only
	New Body						
2007-2013	1500	Reg	6.5ft	No	C2208		
				Yes			
	New Body						
2007-2013	1500	Reg	8ft	No	C2212		
				Yes			
	New Body						
2007-2013	1500	Ext	6.5ft	No	C2207		
				Yes			
	New Body						
2007-2013	1500	Ext	8ft	No	C2207		
				Yes			
	New Body						
ALL	Canyon, Colorado, S10, Sonoma						
2007-2013	1500	Crew	5.5ft	No	C2211		
				Yes			
	New Body						
2011-2014	2500, 3500	Crew, Ext	6.5ft	No	C2213/C2220	C2220A	
				Yes			
	New Body						
2011-2014	2500, 3500	Crew, Ext	8ft	No	C2214/C2219	C2214A	A7732
				Yes	C4204 (4,5)		
	New Body						

Step 3: Select Your Rear Tie Downs

Step 4: Optional Select Your SuperHitch

Step 5: Select Your Suspension Stabilizer

Rear Tie Downs			SuperHitch		StableLoad	
Standard Rear Tie Down	Talon Aluminum Rear Tie Down	Hitch Type	MFG#	Type	MFG#	
No Hitch	C3206	C3206A	Original 20k	C1205 (1B)	Lower	A7310 (1,4)
Factory	C3206	C3206A	Magnum 30k	C1205-30 (1C)		
Superhitch	R3503 (23)	R3503A (23)				
SH Magnum	R3504	R3504A				
Aftermarket	R3501 (12)					
No Hitch		C3206A	Original 20k	C1206 (1B)	Lower	A7310 (1,4)
Factory	C3209 (15)	C3206A	Magnum 30k	C1206-30 (1C)		
Superhitch	R3502	C3206A				
SH Magnum	R3502	C3206A				
Aftermarket	R3500 (12)					
No Hitch		C3206A	Original 20k	C1205 (1B)	Lower	A7310 (1,4)
Factory	C3209 (15)	C3206A	Magnum 30k	C1205-30 (1C)		
Superhitch	R3503 (23)	R3503A (23)				
SH Magnum	R3504	R3504A				
Aftermarket	R3501 (12)					
No Hitch	C3203		Hero 15k	C1210H (1A)	Lower	A7310 (1,4)
Factory	C3203					
SH Hero	R3507	R3507A				
Aftermarket	R3500 (12)					
No Hitch	C3204		Hero 15k	C1210H (1A)	Lower	A7310 (1,4)
Factory	C3204					
SH Hero	R3507	R3507A				
Aftermarket	R3500 (12)					
No Hitch	C3203		Hero 15k	C1210H (1A)	Lower	A7310 (1,4)
Factory	C3203					
SH Hero	R3507	R3507A				
Aftermarket	R3500 (12)					
No Hitch	C3204		Hero 15k	C1210H (1A)	Lower	A7310 (1,4)
Factory	C3204					
SH Hero	R3507	R3507A				
Aftermarket	R3500 (12)				Lower	A7311 (2,4)
No Hitch	C3203		Hero 15k	C1210H (1A)	Lower	A7310 (1,4)
Factory	C3203					
SH Hero	R3507	R3507A				
Aftermarket	R3500 (12)					
No Hitch	C3212	C3212A	Original 20k	C1209 (1B,1,6)	Upper	A7202 (3) (3500 ONLY)
Factory	C3212	C3212A	Magnum 30k	C1209-30 (1C,1,6)		
Superhitch	C3212	C3212A			Lower	A7310 (1,4,5)
SH Magnum	C3212	C3212A				
Aftermarket	R3500 (12)					
No Hitch	C3212	C3212A	Original 20k	C1208 (1B)	Upper	A7202 (3) (3500 ONLY)
Factory	C3212	C3212A	Magnum 30k	C1208-30 (1C)		
Superhitch	C3212	C3212A			Lower	A7310 (1,4,5)
SH Magnum	C3212	C3212A				
Aftermarket	R3500 (12)					

Chevrolet

Step 1: Select Your Front Tie Downs

Step 2: Optional Select Your Auxiliary Power Product HiddenPower Under Vehicle Battery Mount

Year	Model	Cab	Bed	Do running boards extend past the cab?	Front Tie Downs		MFG#
					Standard Front Tie Down	Talon Aluminum Front Tie Down	
2011-2014	2500, 3500	Reg	8ft	No	C2215		
2014-2015	1500	Reg	8ft	No	C2212		
2014-2015	1500	Crew	5.5ft	No	C2218		
2014-2015	1500	All	6.5ft	No	C2217		
2015	2500, 3500	Crew, Double	6.5ft	No	C2220	C2220A	
	Single Rear Wheel						
2015	2500, 3500	Crew, Double	8ft	No	C2219	C2214A	A7732
	Single Rear Wheel			Yes	C4204 (4,5)		(3500 Crew Only)
2015	2500, 3500	Reg	8ft	No	C2215		
	Single Rear Wheel						
2015	3500	Crew, Double	8ft	No	C2219	C2214A	A7732
	Dual Rear Wheel			Yes	C4204 (4,5)		(3500 Crew Only)
2015	3500	Reg	8ft	No	C2215		
	Dual Rear Wheel						
2016	3500	Crew	8ft	No	C2219	C2214A	A7732
	Single Rear Wheel			Yes			(3500 Crew Only)
2016	2500	Crew	6.5ft	No	C2220	C2220A	
	Single Rear Wheel						

Step 3: Select Your Rear Tie Downs

Step 4: Optional Select Your SuperHitch

Step 5: Select Your Suspension Stabilizer

Rear Tie Downs			SuperHitch		StableLoad	
Standard Rear Tie Down	Talon Aluminum Rear Tie Down	Hitch Type	MFG#	Type	MFG#	
No Hitch	C3212	C3212A	Original 20k	C1208 (1B)	Upper	A7202 (3) (3500 ONLY)
Factory	C3212	C3212A	Magnum 30k	C1208-30 (1C)		
Superhitch	C3212	C3212A			Lower	A7310 (1,4,5)
SH Magnum	C3212	C3212A				
Aftermarket	R3500 (12)					
Factory	C3214		Hero 15k	C1210H (1A)	Lower	A7310 (1,4) (2015 Trucks) (7)
SH Hero	R3509	R3509A				
Aftermarket	R3500 (12)					
Factory	C3214		Hero 15k	C1210H (1A)	Lower	A7310 (1,4) (2015 Trucks) (7)
SH Hero	R3509	R3509A				
Aftermarket	R3500 (12)					
Factory	C3214		Hero 15k	C1210H (1A)	Lower	A7310 (1,4) (2015 Trucks) (7)
SH Hero	R3509	R3509A				
Aftermarket	R3500 (12)					
Factory	C3215	C3215A	Original 20k	C1212 (1B)	Upper	A7202 (3) (3500 ONLY)
Superhitch	C3216	C3216A	Magnum 30k	C1212-30 (1C)		
SH Magnum	C3216	C3216A			Lower	A7310 (1,4) (2500 ONLY)
Aftermarket	R3500 (12)					
Factory	C3215	C3215A	Original 20k	C1211 (1B)	Upper	A7202 (3) (3500 ONLY)
Superhitch	C3216	C3216A	Magnum 30k	C1211-30 (1C)		
SH Magnum	C3216	C3216A			Lower	A7310 (1,4)
Aftermarket	R3500 (12)					(2500 ONLY)
Factory	C3215	C3215A	Original 20k	C1211 (1B)	Upper	A7202 (3)
Superhitch	C3216	C3216A	Magnum 30k	C1211-30 (1C)		(3500 ONLY)
SH Magnum	C3216	C3216A			Lower	A7310 (1,4) (2500 ONLY)
Aftermarket	R3500 (12)					
Factory	C3217	C3217A	Original 20k	C1211 (1B)	Upper	A7202 (3)
Superhitch	C3216	C3216A	Magnum 30k	C1211-30 (1C)		
SH Magnum	C3216	C3216A				
Aftermarket	R3500 (12)					
Factory	C3217	C3217A	Original 20k	C1211 (1B)	Upper	A7202 (3)
Superhitch	C3216	C3216A	Magnum 30k	C1211-30 (1C)		
SH Magnum	C3216	C3216A				
Aftermarket	R3500 (12)					
Factory	C3215	C3215A	Original 20k	C1211 (1B)	Upper	A7202 (3)
Superhitch	C3216	C3216A	Magnum 30k	C1211-30 (1C)		(3500 only)
SH Magnum	C3216	C3216A			Lower	A7310 (1,4)
Aftermarket	R3500 (12)					(2500 only)
Factory	C3215	C3215A	Original 20k	C1212 (1B)	Lower	A7310 (1,4)
Superhitch	C3216	C3216A	Magnum 30k	C1212-30 (1C)		(2500 only)
SH Magnum	C3216	C3216A				
Aftermarket	R3500 (12)					

Toyota

Step 1: Select Your Front Tie Downs

Step 2: Optional
Select Your Auxiliary
Power Product
HiddenPower Under
Vehicle Battery Mount

Year	Model	Cab	Bed	Do running boards extend past the cab?	Front Tie Downs		MFG#
					Standard Front Tie Down	Talon Aluminum Front Tie Down	
1998-2004	Tacoma	All	6ft	No	T2306		
2000-2006	Tundra	All	6.5ft	No	T2301		
	Standard Tow Package						
2000-2006	Tundra	All	8ft	No	T2302		
	Standard Tow Package						
2000-2006	Tundra	All	8ft	No	T2302		
	HD Tow Package						
2003-2006	Tundra	All	6.5ft	No	T2301		
	HD Tow Package						
2005-2014	Tacoma	All	All	No	T2303 (18)		
	4x4 only						
2005-2014	Tacoma	All	All	No	T2308 (18)		
	2x4 only						
2007	Tundra	All	6.5ft	No	T2304		
2007	Tundra	All	8ft	No	T2305		
2007	Tundra	Crew Max	5.5ft	No	T2307		
2008-2011	Tundra	All	6.5ft	No	T2304		
	4x4 Only						
2008-2012	Tundra	All	8ft	No	T2305		
2008-2013	Tundra	Crew Max	5.5ft	No	T2307		
	4x4 Only						
2012-2013	Tundra	Double	6.5ft	No	T2309		
2013	Tundra	Double	8ft	No	T2305		
2014-2015	Tundra	Crew Max	5.5ft	No	T2307		
	4x4 only						
2014-2015	Tundra	Double	6.5ft	No	T2309		
	4x4 only						
2014-2015	Tundra	Double	8ft	No	T2305		
2015	Tacoma	Double	6.5ft	No	T2308 (18)		
	4x4 only						
2015	Tacoma	Double	5ft				
	4x4 only						

Step 6: Select Your Turnbuckles

Basic SpringLoad Kit

MFG# S9000



GOOD

BETTER

SpringLoad XL

MFG# S9050A



BEST

FastGun

SS Polished

MFG# S9526

SS Powder Coated Grey

MFG# S9522

SS Powder Coated Black

MFG# S9529

SS Bright White

MFG# S9530



Nissan

Step 1: Select Your Front Tie Downs

Step 2: Optional
Select Your Auxiliary
Power Product
HiddenPower Under
Vehicle Battery Mount

				Front Tie Downs			
Year	Model	Cab	Bed	Do running boards extend past the cab?	Standard Front Tie Down	Talon Aluminum Front Tie Down	MFG#
2000-2004	Frontier	Crew	4.5ft	No	N2407		
		4x4					
2000-2004	Frontier	King, Crew	6ft	No	N2408		
2004-2015	Titan	Crew	5.5ft	No	N2401		
2004-2014	Titan	King	6.5ft	No	N2402 (16)		
2005-2012	Frontier	King, Crew	6ft	No	N2409		
2008	Titan	King	8ft	No	N2405		
2008-2012	Titan	Crew	7ft	No	N2406		
2013-2014	Frontier	King	6ft	No	N2409		
2014	Frontier	Crew	6ft				
		4x4					
2014-2015	Frontier	Crew	5'				
		4x4					
2015	Frontier	King	6ft	No	N2409		
All	NV2500, NV3500	Van	N/A				
All	Xterra	SUV	N/A				

Step 6: Select Your Turnbuckles

Basic SpringLoad Kit

MFG# S9000



GOOD

BETTER

SpringLoad XL

MFG# S9050A



BEST

FastGun

SS Polished

MFG# S9526

SS Powder Coated Grey

MFG# S9522

SS Powder Coated Black

MFG# S9529

SS Bright White

MFG# S9530



Step 3: Select Your Rear Tie Downs

Step 4: Optional Select Your SuperHitch

Step 5: Select Your StableLoad Stabilizer

Rear Tie Downs		SuperHitch		StableLoad	
Standard Rear Tie Down	Talon Aluminum Rear Tie Down	Hitch Type	MFG#	Type	MFG#
No Hitch	N3402			Lower	A7311 (2,4)
Aftermarket	R3500 (12)				
No Hitch	N3402			Lower	A7311 (2,4)
Aftermarket	R3500 (12)				
No Hitch	N3401			Lower	A7311 (2,4,6)
Factory	N3401				
Aftermarket	R3500 (12)				
No Hitch	N3401			Lower	A7311 (2,4,6)
Factory	N3401				
Aftermarket	R3500 (12)				
No Hitch	N3403			Lower	A7311 (2,4)
Factory	N3403				
Aftermarket	R3500 (12)				
No Hitch	N3401			Lower	A7311 (2,4,6)
Factory	N3401				
Aftermarket	R3500 (12)				
No Hitch	N3401			Lower	A7311 (2,4,6)
Factory	N3401				
Aftermarket	R3500 (12)				
No Hitch	N3403			Lower	A7311 (2,4)
Factory	N3403				
Aftermarket	R3500 (12)				
No Hitch	N3403			Lower	A7311 (2,4)
Factory	N3403				
Aftermarket	R3500 (12)				
No Hitch	N3403			Lower	A7311 (2,4)
Factory	N3403				
Aftermarket	R3500 (12)				
No Hitch	N3403			Lower	A7311 (2,4)
Factory	N3403				
Aftermarket	R3500 (12)				
Aftermarket	R3500 (12)			Lower	A7311 (2,4)
				Lower	A7311 (2,4)
				Lower	A7311 (2,4)

Tie Down Footnotes

- 2 Drilling may be required into the Spring Hanger Bracket which is welded to the frame.
- 3 Drilling may be required for installation.
- 4 May require modifications to the running board/bed access step brackets to install Tie Downs.
- 5 Additional labor required for installation of Tie Downs.
- 6 Front Tie Down is available in adjustable Tie Down style only.
- 9 The Toyota HD Tow Package attaches to the side and bottom of the vehicles frame. The Standard Toyota Tow Package attaches to the bottom of the vehicles frame only.
- 10 To determine the correct fit: 1500 & 2500 model/classic body style vehicle owners must measure the vehicle frame height at the back of the truck next to the spare tire. If the frame is 5.5" tall it requires the LD application, if the frame is 8" tall it requires the HD application.
- 11 Will work with aftermarket hitches that do not have side plates that attach to the bottom of the frame.
- 12 Tie Down requires 4"x4" footprint on the side plate of the aftermarket hitch in order to install. Drilling four holes per side is required for install.
- 14 Dually applications may require the use of #A7004 Dually Adapter Kit. Measure from front of camper slide in point to the rear anchor point. If total is 90" or less, use Dually Adapter Kit.
- 15 Requires a Factory installed hitch receiver with an open ended cross tube.
- 16 Designed to work with the factory installed running board that extends past the cab and onto the bed. Tie Down is not adjustable in height.
- 18 Toyota Tacoma models with a 5' bed & running boards under the cab will need to remove the running boards to install this tie down.
- 20 Will not work with aftermarket Mopar rear mounted kick out steps that are mounted under the bumper.
- 22 This Tie Down mounts to the cab mount. You will need to remove the running boards to install this Tie Down.
- 23 If you are using an older one piece SuperHitch, please call 800.246.8132 for rear Tie Down applications.
- 25 There were no factory options for a factory hitch for this vehicle. Hitches that were installed on this truck were dealer installed aftermarket hitch options. Select aftermarket hitch on app guide main page step 3.
- 27 Will not work with HiddenPower due to Tie Down design.
- 28 Works with NO running boards, including the ones that are just under the cab. If you have running boards under your cab, you will need front tie down D2127/D2127A.
- 29 Works with any factory running boards/bed access steps, including the ones that are only under the cab.
- 30 Due to compressor location this Tie Down can't be installed with factory airbags.
- 31 If your truck is equipped with factory airbags and no running boards, use D2126/D2126A. If your truck is equipped with factory airbags and running boards of any length, use D2127/D2127A.

SUPERHITCH OUTLAW SERIES

If you're not sure you're within the law,
have the Outlaw on your side*

*Torklift recommends towing within the capacities set by your vehicle manufacturer.

Truck Camper Suspension Upgrade
Optional. Not required with SuperHitch

ORIGINAL 20K

MAGNUM 30K

YEAR	MODEL (CAB TYPE)	ITEM DESCRIPTION	MFG#		STABLELOAD PART#	STABLELOAD NTP#	STABLE-LOAD PART#	STABLE-LOAD NTP#
FORD								
80-97	F250/F350	All bed lengths	F1000 (1a)	14-1983	A7311 (30)	15-3187	A7200 (31)	15-3180
99-15	F250/F350/F450 Factory Bed	All bed lengths	F1002 (1a,5)	14-1980	A7311 (30)	15-3187	A7200 (31)	15-3180
00-15	F350/F450/F550 Cab and chassis	NA	F1003 (1a,5)	14-4096	-	-	A7200 (31)	15-3180
DODGE								
80-93	D250/D350	Long bed	F1000 (1a,1)	14-1983	-	-	A7200 (31)	15-3180
94-02	2500/3500	Long bed	D1100 (1a,1)	14-1986	A7311 (30)	15-3187	A7200 (31)	15-3180
94-02	2500/3500	Short bed	D1100 (1a,1)	14-1986	A7311 (30)	15-3187	A7200 (31)	15-3180
03-12	2500 HD/3500HD	Long bed and short without factory hitch	D1101 (1a,2)	14-2008	A7311 (30)	15-3187	A7200 (31)	15-3180
03-12	2500 HD/3500 HD	Long bed and short with factory hitch	D1102 (1a,2,3)	14-2007	A7311 (30)	15-3187	A7200 (31)	15-3180
2013	2500HD/3500 HD	Long bed and short with factory hitch	D1104 (1a,2,3)	14-2013	A7311 (30)	15-3187	A7200 (31)	15-3180
14-15	2500	Long bed and short with factory hitch	D1107 (1a,2,3)	25-0094	-	-	-	-
14-15	3500 HD	Long bed and short with factory hitch	D1104 (1a,2,3)	14-2013	A7311 (30)	15-3187	A7200 (31)	15-3180
CHEVY / GMC								
82-87	2500	Long bed	C1200 (1a,2)	14-2001	-	-	-	-
82-90	3500	Long bed	C1200 (1a,2)	14-2001	-	-	-	-
88-98	2500	All bed lengths	C1201 (1a,1)	14-2002	A7310 (30)	15-3181	-	-
91-00	3500	All bed lengths	C1201 (1a,1)	14-2002	A7310 (30)	15-3181	-	-
99-00	2500 LD	Long bed	C1202 (1a)	14-1989	A7310 (30)	15-3181	-	-
01-07	2500 HD/3500 HD classic	Short bed	C1204 (1a,4)	14-2004	A7310 (30)	15-3181	-	-
01-10	2500 HD/3500 HD classic & new body	Long bed	C1205 (1a)	14-1999	A7310 (30)	15-3181	-	-
07-10	2500 HD/3500 HD new body	Short bed	C1206 (1a)	14-2003	A7310 (30)	15-3181	-	-
11-14	2500/3500 HD	Long bed	C1208 (1a)	14-2012	A7310 (30)	15-3181	A7202 (31)	16-3182
11-14	2500/3500 HD	Short bed	C1209 (1a,1,6)	14-2011	A7310 (30)	15-3181	A7202 (31)	16-3182
2015	2500/3500 HD	Long bed	C1211 (1a)	14-0681	-	-	A7202 (31)	16-3182
2015	2500/3500 HD	Short bed	C1212 (1a)	14-0867	-	-	A7202 (31)	16-3182
FORD								
99-15	F250/F350/F450 Factory Bed	All bed lengths	F1002-30 (1b,5)	14-0682	A7311 (30)	15-3187	A7200 (31)	15-3180
00-15	F350/F450/F550 cab and chassis	N/A	F1003-30 (1b,5)	14-0873	-	-	A7200 (31)	15-3180
DODGE								
03-12	2500 HD/3500 HD	Long and short bed with factory hitch	D1102-30 (1b,2,3)	14-0869	A7311 (30)	15-3187	A7200 (31)	15-3180
07-15	STERLING / 3500 /4500 / 5500 HD CAB & CHASSIS/ QUAD CAB & REG		D1103-30 (1b,2,3)	14-0891	A7311 (30)	15-3187	A7200 (31)	15-3180
2013	2500HD/3500 HD	Long and short bed with factory hitch	D1104-30 (1b,2,3)	14-0870	A7311 (30)	15-3187	A7200 (31)	15-3180
14-15	2500 HD	Long and short bed with factory hitch	D1107-30 (1b,2,3)	14-0872	-	-	-	-
14-15	3500 HD	Long and short bed with factory hitch	D1104-30 (1b,2,3)	14-0870	A7311 (30)	15-3187	A7200 (31)	15-3180
CHEVY/GMC								
01-07	2500 HD/3500 HD classic	Short bed	C1204-30 (1b,4)	14-0854	A7310 (30)	15-3181	-	-
01-10	2500 HD/3500 HD classic & new body	Long bed	C1205-30 (1b)	14-0863	A7310 (30)	15-3181	-	-
07-10	2500 HD/3500 HD new body	Short bed	C1206-30 (1b)	14-0864	A7310 (30)	15-3181	-	-
11-14	2500/3500 HD	Long bed	C1208-30 (1b)	14-0652	A7310 (30)	15-3181	A7202 (31)	16-3182
11-14	2500/3500 HD	Short bed	C1209-30 (1b,1,6)	14-0865	A7310 (30)	15-3181	A7202 (31)	16-3182
2015	2500/3500 HD	Long bed	C1211-30 (1b)	14-0866	-	-	A7202 (31)	16-3182
2015	2500/3500 HD	Short bed	C1212-30 (1b)	14-0868	-	-	A7202 (31)	16-3182



OVER 35 YEARS OF INNOVATION, QUALITY, SAFETY.

The latest 2016 part numbers are just a click away! Visit the online automated application guide available 24/7 at TORKLIFT.COM

For fast and friendly tech support call us at 1-800-246-8132

SUPERTRUSS	LENGTH	MFG#	DEAD WEIGHT	WEIGHT DISTRIBUTING	
	21"	E1521	14-2020	750 / 7,500	1,400 / 14,000
	24"	E1524	14-2023	750 / 7,500	1,400 / 14,000
	28"	E1528	14-2026	750 / 7,500	1,200 / 12,000
	32"	E1532	14-2027	650 / 6,500	1,200 / 12,000
	36"	E1536	14-2029	650 / 6,500	1,200 / 12,000
	42"	E1542	14-2032	600 / 6,000	1,200 / 12,000
	48"	E1548	14-2035	600 / 6,000	1,200 / 12,000
	60"	E1560	14-2036	500 / 5,000	1,000 / 10,000
	MFG#	NTP#	SuperTruss Extension SkidWheel		
	A7100	15-1003			

EVEREST 30K	MFG#	ITEM DESCRIPTION	
	WD1000	14-7140	Industry's highest ratings of 3,000lbs tongue weight and 30,000lbs towing
	WP1001	Call	Friction plate replacement kit: Prevents friction between yoke and ballmount.
	WP1002	Call	Separate set of hook up clips for hydraulic assist.
	WP1003	Call	Separate set of cam over leverage arms for engaging hook up clips

BALLMOUNTS	MFG#	NTP#	ITEM DESCRIPTION	MAX CAPACITY
	M9000	14-1988	Magnum Drop Shank	30,000 lbs.
	M9001	14-1990	Magnum Drop Shank XL	30,000 lbs.
	M9005	14-1994	Magnum Ballmount Adapter	20,000 lbs.
	M9002	14-1991	Magnum Pintle Adapter	20,000 lbs.
	M9003	14-1992	Magnum Pintle Shank	17,000 lbs.
	M9004	14-1993	Magnum Ballmount Adapter	17,000 lbs.
	M9006	14-1995	Magnum 2.5" To 2" Adapter Sleeve	N/A
	M9008	14-1997	Magnum 30k Trailer Ball	30,000 lbs.
	M9010	14-1969	Everest 30K Shank	30,000 lbs.
	M9011	14-1970	Everest 30K Shank XL	30,000 lbs.

SuperHitch Footnotes

- 1B Rated at 2,000 lbs tongue weight distributing and 20,000 lbs pulling capacity weight distributing.
- 1C Rated at 3,000 lbs tongue weight distributing and 30,000 lbs pulling capacity weight distributing.
- 1 Spare tire hanger and tailpipe modification may be necessary.
- 2 May require modification to spare tire hanger.
- 3 Will only work with factory welded on receiver hitch .
- 4 2007 fits only classic body style.
- 5 Trucks with 34½" cab and chassis frame use F1003; trucks with a 37½" regular pickup frame use F1002.
- 6 Works with vehicles that have factory rims and tires 18" and smaller.

StableLoad Footnotes

- 30 Uses lower overload and is no-drill on most applications. StableLoad is the preferred suspension upgrade for all trucks. Visit torklift.com for installation/footnote details. Lower overload required. Caution: A7311 is only required if there is no pre-drilled hole in the lower overload, otherwise use A7310 for pre-drilled lower overloads. Not required for SuperHitch installation. One set per truck is necessary.
- 31 Uses upper overload and is no-drill. StableLoad is the preferred suspension upgrade for all trucks. Visit torklift.com for installation/footnote details. Upper overload required. Not required for SuperHitch installation.



OVER 35 YEARS OF INNOVATION, QUALITY, SAFETY.

The latest 2016 part numbers are just a click away! Visit the online automated application guide available 24/7 at TORKLIFT.COM

For fast and friendly tech support call us at 1-800-246-8132



STABLELOAD

Suspension Stabilizer



Quick Disconnect Model Shown Above

YEAR	MAKE/MODEL	MFG#	NTP#	MFG#	NTP#
UNIVERSAL					
Universal	Truck/SUV/Van/RV/Commercial, etc	A7311 (2,4)	15-3187	A7202 (3)	15-3182
FORD					
All	Ranger	A7311 (2,4)	15-3187	-	-
81-09	F150/250/350/450	A7311 (2,4)	15-3187	A7200 (3)	15-3180
10-14	F150	A7310 (1,4)	15-3181	-	-
10-15	F250/350/450	A7310 (1,4)	15-3181	A7200 (3)	15-3180
00-15	F350/450/550 Cab and Chassis	-	-	A7200 (3)	15-3180
01-08	E150 Van	A7311 (2,4)	15-3187	-	-
05-11	E250/E350 Van	A7311 (2,4,5)	15-3187	-	-
12-13	E250/E350 Van	A7310 (1,4,5)	15-3181	-	-
DODGE					
95-08	1500	A7311 (2,4)	15-3187	-	-
95-13	2500/3500/4500	A7311 (2,4,8)	15-3187	A7200 (3,8)	15-3180
14-15	3500/4500	A7311 (2,4,8)	15-3187	A7200 (3,8)	15-3180
14-15	4500/5500 Cab and Chassis	-	-	A7200 (3)	15-3180
All	Dakota	A7311 (2,4)	15-3187	-	-
CHEVROLET/GMC					
00-13	2500 Suburban/YukonXL	A7310 (1,4)	15-3181	-	-
All	Canyon/Colorado/S10/Sonoma	A7311 (2,4)	15-3187	-	-
88-14	1500 trucks	A7310 (1,4)	15-3181	-	-
2015	1500 trucks	A7310 (1,4,7)	15-3181	-	-
88-10	3500 trucks	A7310 (1,4,5)	15-3181	A7200 (3)	15-3180
11-14	3500 trucks	A7310 (1,4,5)	15-3181	A7202 (3)	15-3182
2015	3500 trucks	-	-	A7202 (3)	15-3182
88-15	2500 trucks	A7310 (1,4)	15-3181	-	-
All	Express/Savana 2500/3500	A7310 (1,4)	15-3181	-	-
TOYOTA					
All	Tacoma	A7311 (2,4)	15-3187	-	-
All	Tundra	A7311 (2,4)	15-3187	-	-
NISSAN					
All	Frontier	A7311 (2,4)	15-3187	-	-
All	Xterra	A7311 (2,4)	15-3187	-	-
All	Titan	A7311 (2,4,6)	15-3187	-	-
All	NV 2500/3500	A7311 (2,4)	15-3187	-	-
HUMMER					
All	H3 SUVs	A7311 (2,4)	15-3187	-	-
MERCEDES					
11-13	Sprinter 2500/3500	A7311 (2,4)	15-3187	-	-

StableLoad Footnotes

- A7310 StableLoad is a NO DRILL APPLICATION and requires factory predrilled 1/2" diameter holes in lower overload spring. The A7310 Quick Disconnect StableLoad is designed for vehicles that have a lower overload leaf suspension with a hole near each end of the lower overload spring. The lower overload will, for the most part be shorter, thicker and will generally have separation from the rest of the spring pack. In most cases, there will be a plastic disk covering the hole in question.
- A7311 (WITH DRILL KIT) will fit any passenger or commercial vehicle, van, SUV, truck, RV etc. with rear leaf springs and lower overload spring. The lower overload leaf can be identified by being on the very bottom of the spring pack, being thicker than the rest of the leaf springs in the spring pack and generally speaking having a gap between the lower overload leaf spring and the upper leaf spring pack. Drilling four 7/16 holes required. Specially treated drill bits and detailed drilling instructions are included. Average drill time is 30-40 minutes for complete installation. Many factory overload springs come predrilled with 1/2" holes. Therefore drilling holes in the overload springs in the same factory locations found on vehicles with predrilled holes will have no effect on your springs integrity or operation. The drilled springs (when drilled in accordance with the Torklift International drilling specifications) and the integrity of the springs once drilled are covered under the Lifetime Torklift International Warranty. Some overload springs may have adhesive padding on top of the overload spring. Use a screwdriver or equivalent to remove the padding. This will ensure proper rotation and ease of use.
- The A7200, A7202 is a NO DRILL APPLICATION and must have factory installed upper overload. Will not work in conjunction with Supersprings. Due to factory overload engagement design, some applications have progressive engagement, where rear springs will contact first. Drilling of rubber pad on some older Dodge applications may be required. Depending on the vehicle model, suspension package, and condition, actual distance between the StableLoad and vehicle frame overload contact bracket may vary. In some rare instances, when the vehicle is not carrying a load, the StableLoad may come into contact on occasion due to rough road conditions and other anomalies. #A7201 Spacer kit is available for vehicles that need additional spacing for the StableLoad to contact the overload spring.
- On Quick Disconnect StableLoad (part#s A7310/A7311) due to wear and tear after time, some vehicles leaf springs may have minimal clearance with the lower overload for StableLoad engagement / disengagement when the vehicle is unloaded. In order for the StableLoad to engage and disengage with minimal effort, a minimum gap of 1/8" is required between the lower overload and the spring pack.
- There is no fit for the 3500/E350 Cab and Chassis.
- If your Nissan Titan has an Axle wrap bracket located at the rear of the lower leaf spring, A7310/A7311 StableLoads may only be installed on the forward end of the driver and passenger leaf springs.
- Due to clearance issues, the stable load will only work on the rear of the spring.
- Will not work with factory installed airbags on 3500 trucks. This is due to the lack of both upper and lower overload springs.