

WIRING INSTALLATION INSTRUCTIONS FOR METAL CARGO TRAY

1. Place grommets into opening on rear of cargo tray on each side.



2. Check to make sure the grommet is seated correctly from the inside of the carrier.



3. Firmly press tail lamp housings into grommets on both sides of cargo tray.



4. Route the 3-way plug with a Yellow wire from under the cargo tray up through the steel grate directly behind the tail lamp housing on driver side of the cargo tray.



5. Plug the harness into the back of the tail lamp housing.



6. Route the 3-way plug with Green wire under the cargo tray over to the passenger side tail lamp. Repeat step 5 for this plug.



7. Cover wires with black tubing and secure the harness with cable ties to the bottom of the tray.



8. Route 4-flat to the front of the tray and avoid any locations that could cut or pinch the wires.