MAKE/ MODEL	BASE CURB WEIGHT	SPEED/ DISTANCE LIMITS	TOWABLE WITH MANUAL TRANS.	TOWABLE WITH AUTO TRANS.	MILEAGE CITY/ HWY.	APPROX. RETAIL PRICE	SPECIAL PROCEDURES (SEE OWNER'S MANUAL FOR DETAILED INSTRUCTIONS)
BUICK Enclave FWD/AWD	4,724/4,922	65 MPH/None	N/A	Yes	17/24-16/22	\$39,270-\$46,450	Run engine at beginning of day and at each fuel stop for 5 minutes. Remove 15-amp ECM and OnStar fuses, and 50-amp BATT1 fuse.
Regal	3,600/3,671	60 MPH/None	Yes	No	19/31-25/36	\$29,900-\$35,865	Run engine at beginning of day and at each fuel stop for 5 minutes.
CADILLAC SRX FWD/AWD CHEVROLET	4,277/4,442	65 MPH/None	N/A	Yes	17/24-16/23	\$38,050-\$45,920	Run engine at beginning of day and at each fuel stop for 5 minutes. Remove shift lever boot. Press and hold manual release button.
Avalanche 4WD	5,803	None	N/A	Yes	15/21	\$38,355-\$40,025	Requires optional Active, 2-Speed Transfer Case.
Cruze	3,102	65 MPH/None	Yes	No	28/42	\$16,720-\$23,110	Remove fuses 22, 23, 24 and 25 from fuse block.
Equinox	3,777	65 мрн/None	N/A	Yes	22/32	\$24,015-\$31,775	Run engine at beginning of day and at each fuel stop for 5 minutes. Remove fuse 32.
Equinox AWD	3,922	65 мрн/None	N/A	Yes	20/29	\$26,765-\$33,525	Run engine at beginning of day and at each fuel stop for 5 minutes. Remove fuse 32.
Silverado 1500 4WD	4,892	None	N/A	Yes	15/21	\$24,585-\$42,930	
Silverado 1500 4WD Hybrid	5,882	None	N/A	Yes	20/23	\$45,255-\$52,035	
Sonic	2,690	65 MPH/None	Yes	Yes*	26/35	\$13,735-\$18,495	Run engine at beginning of day and at each fuel stop for 5 minutes. Remove fuse DLIS. *1.8 model only
Spark	2,269	55 MPH/None	Yes	No	32/38	\$12,995-\$16,720	
Suburban 1500 4WD	5,824	None	N/A	Yes	15/21	\$47,630-\$60,680	Requires optional Active, 2-Speed Transfer Case.
Tahoe 4WD	5,567	None	N/A	Yes	15/21	\$44,885-\$58,145	Requires optional Active, 2-Speed Transfer Case.
Tahoe 4WD Hybrid		None	N/A	Yes	20/23	\$56,845	
Traverse	4,713	65 MPH/None	N/A	Yes	17/24	\$31,370-\$41,285	Run engine at beginning of day and at each fuel stop for 5 minutes. Remove 15-amp ECM and OnStar fuses, and 50-amp BATT1 fuse.
Traverse AWD	4,956	65 MPH/None	N/A	Yes	16/23	\$33,370-\$43,285	Run engine at beginning of day and at each fuel stop for 5 minutes. Remove 15-amp ECM and OnStar fuses, and 50-amp BATT1 fuse.
DODGE	1.000	CE MOU! None	Vac	No	10/07	¢2E 70E ¢44 77E	Transmission in MEUTRAL
Challenger Dart	4,082 3,186	65 MPH/ None None	Yes	No No	18/27 25/36		Transmission in NEUTRAL. Transmission in NEUTRAL.
Durango R/T AWD 5.7-L V-8	5,330	None	N/A	Yes	13/20		Requires 2-Speed Transfer Case. Transmission in PARK, transfer case set to NEUTRAL.
Ram 1500 4WD	4,893	None	N/A	Yes	16/24	\$23,595-\$46,270	Transmission in PARK, transfer case set to NEUTRAL.
Ram 2500 4WD	5,997	None	Yes	Yes	Not Rated	\$31,405-\$48,875	For automatic transmissions, shift into PARK; manual trans-

MAKE/ MODEL	BASE CURB WEIGHT	SPEED/ DISTANCE LIMITS	TOWABLE WITH MANUAL TRANS.	TOWABLE WITH AUTO TRANS.	MILEAGE CITY/ HWY.	APPROX. RETAIL PRICE	SPECIAL PROCEDURES (SEE OWNER'S MANUAL FOR DETAILED INSTRUCTIONS)
							missions place in gear, not NEUTRAL. Manual and electronic shift transfer cases must be in NEUTRAL: See "Shifting Into Neutral," in owner's manual.
Ram 3500 4WD	7,152	None	No	Yes	Not Rated	\$39,520-\$56,570	For automatic transmissions, shift into PARK; manual transmissions place in gear, not NEUTRAL. Manual and electronic shift transfer cases must be in NEUTRAL: See "Shifting Into Neutral," in owner's manual.
500	2,358	None	Yes	No	31/40	\$15,500-\$17,500	Transmission in NEUTRAL.
500 Cabrio	2,408	None	Yes	No	31/40	\$19,500-\$23,500	Transmission in NEUTRAL.
FORD							
C-MAX Energi	3,899	65 MPH/None	N/A	Yes	108/92	\$33,745	Run engine at beginning of day for 5 minutes (shift into DRIVE, then REVERSE and NEUTRAL) and every 6 hours thereafter.
C-MAX Hybrid	3,640	65 MPH/None	N/A	Yes	47/47	\$24,995-\$27,995	Run engine at beginning of day for 5 minutes (shift into DRIVE, then REVERSE and NEUTRAL) and every 6 hours thereafter.
Edge 3.5-L/3.7-L	4,056	65 MPH/None	N/A	Yes	19/27	\$25,850-\$35,435	Run engine at beginning of day for 5 minutes (shift into DRIVE, then REVERSE and NEUTRAL) and every 6 hours thereafter.
Explorer 3.5-L	4,534-4,697	65 MPH/None	N/A	Yes	17/24	\$28,460-\$40,045	Run engine at beginning of day for 5 minutes (shift into DRIVE, then REVERSE and NEUTRAL) and every 6 hours thereafter.
F-150 4WD	4,925	None	N/A	Yes	16/21	\$28,310-\$52,455	Turn ignition to ON, press and hold brake pedal, move 4WD switch to 2H, shift transmission to NEUTRAL. Rotate 4WD switch from 2H to 4L and back five times. Turn ignition as far as it will go toward OFF. Leave key in ignition while towing.
F-250/F-350/F-450 Super Duty 4WD	6,985	None	N/A	Yes	Not Rated	\$29,455-\$65,140	Only 4WD models with manual-shift transfer case (not Electronic Shift-Onthe-Fly) are towable. Shift manual transfer case into NEUTRAL, set hub locks to FREE.
Fiesta	2,578	70 MPH/None	Yes	Yes	29/37	\$13,745-\$17,600	For automatic transmission, but no push-button start: release parking brake; turn ignition to II; press brake pedal, shift into NEUTRAL; turn ignition key to OFF position, release brake pedal; disconnect negative cable from battery. After towing, start engine within 15 minutes of reconnecting battery cable. For automatic transmission and push-button start: release parking brake; activate ignition, press START/STOP button, press brake pedal, then shift to NEUTRAL and release

MAKE/ MODEL	BASE CURB WEIGHT	SPEED/ DISTANCE LIMITS	TOWABLE WITH MANUAL TRANS.	TOWABLE WITH AUTO TRANS.	MILEAGE CITY/ HWY.	APPROX. RETAIL PRICE	SPECIAL PROCEDURES (SEE OWNER'S MANUAL FOR DETAILED INSTRUCTIONS)
							brake pedal; deactivate ignition, press start/stop button, disconnect negative cable from the battery. After towing, start engine within 15 minutes of reconnecting battery cable.
Flex	4,471-4,643	65 MPH/None	N/A	Yes	18/25	\$28,210-\$36,555	Run engine at beginning of day for 5 minutes (shift into DRIVE, then REVERSE and NEUTRAL) and every 6 hours thereafter.
Focus	2,907	70 MPH/None	Yes	Yes	26/36	\$15,495-\$24,495	For automatic transmission, but no push-button start: release parking brake; turn ignition to II; press brake pedal, shift into NEUTRAL; turn ignition key to OFF position, release brake pedal; disconnect negative cable from battery. After towing, start engine within 15 minutes of reconnecting battery cable. For automatic transmission and push-button start: release parking brake; activate ignition by pressing START/STOP button; press brake pedal, then shift to NEUTRAL and release brake pedal; deactivate ignition by pressing START/STOP button; disconnect negative cable from the battery. After towing, start engine within 15 minutes of reconnecting battery cable.
Fusion	3,333	70 MPH/None	Yes	No	25/37	\$21,700	Transmission in NEUTRAL.
Fusion Energi	3,913	70 MPH/None	N/A	Yes	N/A	N/A	Start engine and allow it to run for 5 minutes at the beginning of each day and every 6 hours thereafter.
Fusion Hybrid	3,615	70 MPH/None	N/A	Yes	47/47	\$27,200	Start engine and allow it to run for 5 minutes at the beginning of each day and every 6 hours thereafter. Select "Neutral Tow" mode — refer to owner's manual.
Taurus 3.5-L	3,969-4,196	65 MPH/None	N/A	Yes	19/29	\$27,395-\$36,995	Run engine at beginning of day for 5 minutes (shift into DRIVE, then REVERSE and NEUTRAL) and every 6 hours thereafter.
Acadia FWD/AWD	4,656/4,850	65 MPH/None	N/A	Yes	17/24-16/23	\$35,070-\$46,965	Run engine at beginning of day and at each fuel stop for 5 minutes. Remove 15-amp ECM and OnStar fuses, and 50-amp BATT1 fuse.
Sierra 1500 4WD	4,877	None	N/A	Yes	14/18	\$27,330-\$43,085	Transfer case must be set to NEUTRAL.
Sierra 1500 4WD Hybrid	5,791	None	N/A	Yes	20/23	\$44,705-\$51,485	Transfer case must be set to NEUTRAL.
Terrain FWD/AWD	3,853	65 MPH/None	N/A	Yes	22/32-20/29	\$26,660-\$32,995	Run engine at beginning of each day and at each fuel stop for 5 minutes. Remove fuse 32. After towing, let engine idle for more than 3 minutes before driving vehicle.

MAKE/ MODEL	BASE CURB WEIGHT	SPEED/ DISTANCE LIMITS	TOWABLE WITH MANUAL TRANS.	TOWABLE WITH AUTO TRANS.	MILEAGE CITY/ HWY.	APPROX. RETAIL PRICE	SPECIAL PROCEDURES (SEE OWNER'S MANUAL FOR DETAILED INSTRUCTIONS)
Yukon 4WD	5,567	None	N/A	Yes	15/21	\$45,440-\$49,770	Only 4WD models equipped with a 2-speed automatic transfer case are towable.
Yukon 4WD Hybrid	5,917	None	N/A	Yes	20/23	\$56,625	Transfer case must be set to NEUTRAL.
Yukon XL 1500 4WD	5,824	None	N/A	Yes	15/21	\$47,690-\$51,870	Only 4WD models equipped with a two-speed automatic transfer case are towable.
HONDA CR-V	3,305	65 MPH/None	N/A	Yes	23/31	\$22,795-\$29,045	Start engine, press brake pedal, move shifter through all positions, shift into DRIVE and hold for 5 seconds, then to NEUTRAL and let engine run for 3 minutes. Repeat at least every 8 hours thereafter. When towing for long periods, remove 7.5-A radio fuse.
CR-V 4WD	3,426	65 MPH/None	N/A	Yes	22/30	\$24,045-\$30,295	Start engine, press brake pedal, move shifter through all positions, shift into DRIVE and hold for 5 seconds, then to NEUTRAL and let engine run for 3 minutes. Repeat at least every 8 hours thereafter. When towing for long periods, remove 7.5-A radio fuse.
Fit	2,496-2,577	65 MPH/None	Yes	Yes*	28/35	\$15,425-\$19,790	*On automatic transmission models, run engine at the beginning of each day, press brake pedal and move shifter through all positions, shift into DRIVE and hold for 5 seconds, then to NEUTRAL and let engine run for 3 minutes. Repeat at least every 8 hours thereafter. When towing for long periods, remove 30A radio fuse.
HYUNDAI							
Accent	2,396	None	Yes	No	28/37	\$14,545-\$16,095	
Elantra (all)	2,661	None	Yes	No	28/38	\$16,815-\$18,395	
Tucson GL FWD	3,319	None	Yes	No	22/29	\$19,245	
Genesis Coupe	3,362	None	Yes	No	21/30	\$22,250	
Veloster	2,584	None	Yes	No	27/37	\$17,450	
Veloster Turbo	2,800	None	Yes	No	24/35	\$21,950	
G37S Sport 6MT Convertible	4,149	70 мрн/500 miles	Yes	No	16/24	\$52,000	Idle engine in NEUTRAL for 2 minutes every 500 miles.
G37S Sport 6MT Coupe	3,708	70 мрн/500 miles	Yes	No	17/25	\$50,500	Idle engine in NEUTRAL for 2 minutes every 500 miles.
G37S Sport 6MT Sedan	3,709	70 мрн/500 miles	Yes	No	17/25	\$41,500	Idle engine in NEUTRAL for 2 minutes every 500 miles.
JEEP							
Compass	3,101	None	Yes	No	23/30	\$19,210-\$24,495	
Compass 4WD	3,216	None	Yes	No	23/28	\$21,395-\$26,395	
Grand Cherokee Limited and Overland	4,850	None	N/A	Yes	16/23	\$26,995-\$42,995	Only 4WD vehicles with Quadra-Trac II (V-6 models) and Quadra-Drive II systems

MAKE/ MODEL	BASE CURB WEIGHT	SPEED/ DISTANCE LIMITS	TOWABLE WITH MANUAL TRANS.	TOWABLE WITH AUTO TRANS.	MILEAGE CITY/ HWY.	APPROX. RETAIL PRICE	SPECIAL PROCEDURES (SEE OWNER'S MANUAL FOR DETAILED INSTRUCTIONS)
							(V-8 models) are towable. Shift transfer case to NEUTRAL, transmission must be in PARK. See "Shifting Into Neutral," in owner's manual.
Patriot 2WD	3,111	None	Yes	No	23/30	\$15,995-\$23,795	
Patriot 4WD	3,263	None	Yes	No	23/28	\$17,995-\$25,695	
Wrangler 4WD	3,760	None	Yes	Yes	17/21	\$22,045-\$29,995	With engine off, press brake pedal, shift automatic transmission into NEUTRAL or press clutch pedal on manual transmissions, shift transfer case lever into NEUTRAL, start engine. Shift transmission into REVERSE, release brake pedal (and clutch pedal on manual transmissions) for 5 seconds, shift automatic transmission in DRIVE or manual transmission in first gear, release brake pedal (and clutch pedal on manual transmissions) for 5 seconds. Turn engine off, apply parking brake, shift transmission into PARK or place manual transmission in gear (not in NEUTRAL), hook up vehicle to tow bar, release parking brake.
Wrangler Unlimited 4WD	4,075	None	Yes	Yes	16/20	\$25,695-\$34,095	With engine off, press brake pedal, shift automatic transmission into NEUTRAL or press clutch pedal on manual transmission, shift transfer case lever into NEUTRAL, start engine. Shift transmission into REVERSE, release brake pedal (and clutch pedal on manual transmissions) for 5 seconds, shift automatic transmission in DRIVE or manual transmission in first gear, release brake pedal (and clutch pedal on manual transmissions) for 5 seconds. Turn engine off, apply parking brake, shift transmission into PARK or place manual transmission in gear (not in NEUTRAL), hook up vehicle to tow bar, release parking brake.
LINCOLN MKS FWD/AWD	1 201 1 120	GE NDI /N	NI/A	Ver	17/05 10/07	¢40,010,¢40,000	Dun angine at harianing of
MKS FWD/AWD	4,204-4,436	65 MPH/None	N/A	Yes	1//25-18/27	\$42,810-\$49,800	Run engine at beginning of day for 5 minutes (shift into DRIVE, then REVERSE and NEUTRAL) and every 6 hours thereafter.
MKT 3.7-L FWD/AWD	4,702-4,942	65 MPH/None	N/A	Yes	17/25-16/23	\$45,285-\$47,280	Run engine at beginning of day for 5 minutes (shift into DRIVE,then REVERSE and NEUTRAL) and every 6 hours thereafter.
MKX 3.7-L FWD/AWD	4,236-4,413	65 мрн/None	N/A	Yes	19/26-17/23	\$39,545-\$41,395	Run engine at beginning of day for 5 minutes (shift into DRIVE, then REVERSE and NEUTRAL) and every 6 hours thereafter.

www.motorhome.com 2013 GUIDE TO DINGHY TOWING | **21**

MAKE/ MODEL	BASE CURB WEIGHT	SPEED/ DISTANCE LIMITS	TOWABLE WITH MANUAL TRANS.	TOWABLE WITH AUTO TRANS.	MILEAGE CITY/ HWY.	APPROX. RETAIL PRICE	SPECIAL PROCEDURES (SEE OWNER'S MANUAL FOR DETAILED INSTRUCTIONS)
MKZ 3.7-L FWD/AWD	3,719-3,874	4 65 MPH/None	N/A	Yes	22/33-22/31	\$35,925-\$39,045	Run engine at beginning of day for 5 minutes and every 6 hours thereafter. See "Neutral Tow," in owner's manual.
MKZ Hybrid	3,828	70 MPH/None	N/A	Yes	45/45	\$35,925	Run engine for 1 minute at beginning of day (shift into DRIVE, then REVERSE and NEUTRAL). See "Neutral Tow," in owner's manual.
NISSAN 370Z Coupe	3,245	70 мрн/500 miles	Yes	No	18/26	\$33,910	Idle engine in NEUTRAL for 2
3702 Goupe	3,243	70 WFH/300 IIIIles	163	NO	10/20	ψ55,510	minutes every 500 miles.
370Z Roadster	3,459	70 мрн/500 miles	Yes	No	18/25	\$44,960	Idle engine in NEUTRAL for 2 minutes every 500 miles.
Cube	2,768	60 мрн/500 miles	Yes	No	25/30	\$17,550	Idle engine in NEUTRAL for 2 minutes every 500 miles. Models with Continuously Variable Transmission (CVT) are not flat towable.
Frontier King/ Crew Cab 2WD I-4	3,690	None/500 miles	Yes	No	19/23	\$20,085	Idle engine in NEUTRAL for 2 minutes every 500 miles.
Frontier King/ Crew Cab 2WD V-6	4,152	None/500 miles	Yes	No	16/20	\$23,965	Idle engine in NEUTRAL for 2 minutes every 500 miles.
Frontier King/ Crew Cab 4WD V-6	4,294	None/500 miles	Yes	No	15/19	\$27,915	Place transfer case in 2H range. Idle engine in NEUTRAL 2 minutes every 500 miles.
Juke FWD SL, SV	2,959	70 мрн/500 miles	Yes	No	27/32	\$21,481	Idle engine in NEUTRAL for 2 minutes every 500 miles.
Sentra	2,822	None/500 miles	Yes	No	27/36	\$15,990	Idle engine in NEUTRAL for 2 minutes every 500 miles.
Versa	2,345	None/500 miles	Yes	No	27/36	\$10,990	Idle engine in NEUTRAL for 2 minutes every 500 miles.
Xterra Manual 4WD S	4,143	None/500 miles	Yes	No	16/20	\$29,295	On 4WD models, place transfer case in 2H range. Idle engine in NEUTRAL for 2 minutes every 500 miles.
Forester 2.5X	3,250	None	Yes	No	21/27	\$21,295-\$24,295	
Impreza 2.0i	2,911	None	Yes	No	25/34	\$17,895-\$20,795	
Impreza WRX	3,208	None	Yes	N/A	19/25	\$25,795-\$29,295	
Impreza WRX STI	3,384	None	Yes	N/A	17/23	\$34,295-\$37,645	STI requires driver's control center differential (DCCD) be set in MANUAL mode and DCCD control dial be set to the farthest rearward position.
Legacy 2.5i	3,315	None	Yes	No	21/28	\$20,295	
Outback 2.5i	3,423	None	Yes	No	19/27	\$23,495- \$29,095	
XV Crosstrek	3,087	None	Yes	No	23/30	\$21,995-\$22,995	
TOYOTA Corolla	2,734	None	Yes	No	27/34	\$16,230-\$18,230	After towing, idle engine for at least 3 minutes before driving.
Matrix 1.8-L	2,844	None	Yes	No	26/32	\$19,275	After towing, idle engine for at least 3 minutes before driving.
Matrix 2.4-L	2,976	None	Yes	No	21/28	\$20,265	After towing, idle engine for at least 3 minutes before driving.
Yaris	2,295	None	Yes	No	30/37	\$14,370-\$16,480	After towing, idle engine for at least 3 minutes before driving.