

The Premium Gold Resin in your RVPRO10000™ will give you many years of soft water. However, if you accidentally cause resin to be released or you destroy the resin by subjecting it to too much heat, too much iron, or too much chlorine resulting in diminished water softening capacity, you can recharge your RVPRO10000™ with new resin by carefully following the given steps:

1. Remove the old resin from the tank before removing the top. The distribution tube is off center, so trying to remove the top from the tank before removing the resin could damage the tube. The resin will need to be removed through the ¾" fill port. Adding water to the tank will help.
2. After all of the old resin has been removed, you can unscrew the black top from the black tank.
3. There will be two holes in the underside of the top. One is for the distribution tube and the other one is for the fill port. Do not put the distribution tube in the fill port hole.
4. There will be an oring underneath the top that you removed from the tank. Do not misplace this. The oring needs to be lubed with silicone grease if it is dry.
5. Clean out the tank. You can rinse it with a mild bleach solution to sanitize it, but thoroughly rinse it out before the next step.
6. Carefully reassemble the top to the tank making sure the oring is in place and the distribution tube is in the correct hole.
7. Now the tedious part. Remove the fill port plug. The resin must be placed through this ¾" opening. Place all of the new resin in the tank. If it appears full, lift it off of the ground about 3" and drop it on a hard surface.

## IF IRON IS IN YOUR WATER

AN IRON PRESENCE IN THE WATER WILL ACCUMALATE AND INTERFERE WITH YOUR SOFTENER'S ABILITY TO FUNCTION PROPERLY. USE **1 OR 2 TEASPOONS** OF POWDERED IRON-OUT FOR WATER SOFTENERS ALONG WITH THE SALT EACH TIME YOU REGENERATE **IF IRON IS PRESENT**. FLUSH THOROUGHLY (2 TO 3 MINUTES). IRON-OUT IS AVAILABLE LOCALLY AT HARDWARE AND WATER TREATMENT STORES. **WHEN REGENERATING IT HELPS TO LAY YOUR SOFTENER ON ITS SIDE, ROLL IT BACK AND FORTH. THIS LOOSENS THE RESIN BED AND SURROUNDS IT WITH THE SALT WATER, AFTER ROLLING IT BACK AND FORTH STAND IT UP TO REGENERATE.**