WIRELESS TOUCH SCREEN GUIDELINES

ELECTRONICS

Purpose

This feature was added to the wireless remotes to provide personalized security for the remote, as well as a safety feature to prevent inadvertent activation of functions. To utilize this set of guidelines, the unit **MUST** be equipped with a multifunction board and the touch screen remote. These guidelines do not apply to any other remote.

To reset PIN Code

- 1. Press "HOME" button to turn on transmitter.
- **2.** Press and release "HOME" button five times.
- **3.** Press "CONFIG" (Fig. 1).
- **4.** The screen will ask you if you want to reset the screen lock PIN code (Fig. 2).
- 5. The screen will notify you that a PIN has been reset (Fig. 3).





- **6.** Press "Home" button and touch "Set PIN" button (Fig. 4).
- **7.** Enter 4-digit code of your choice (Fig. 5).
- **8.** Touch "Save" button (Fig. 6).







NOTE: To start programming over, push and hold the "Home" button for 5 secs to turn off the remote. Push the "Home" button again to turn the remote back on and restart the programming procedure.



WIRELESS TOUCH SCREEN GUIDELINES

ELECTRONICS

- **9.** Locate the LCI Wireless Remote and press the silver "Home" button to begin.
- **10.** When the keypad appears on the screen, enter the 4-digit PIN by pressing the corresponding numbers on the touch screen (Fig. 7).

Menu Screen Options

- 1. The menu screen will show the first four function options. Select one or press the "Next" button for more options (Fig. 8).
- **2.** To return to previous menu screen press the "Prev" button (Fig. 9).



3. Light functions can be turned on and off by pressing the button on the menu screen (Fig. 10A).

To operate slides, awnings, etc.

- 1. Press component button on menu screen to enter function operations screen. This screen will display: on- off, or arrow up- down, or arrow in- out button options (Fig. 11). To return to previous screen, press the "Home" button (Fig. 7).
- **2.** The remote will enter "Sleep Mode" after 60 seconds of inactivity.





As a supplier of components to the RV industry, safety, education and customer satisfaction are our primary concerns. Should you have any questions, please do not hesitate to contact us at (574) 537-8900 or by email at customerservice@lci1.com. Self-help tips, technical documents, product videos and a training class schedule are available at www.lci1.com or by downloading the MyLCI app.