DISH Compatible Satellite Antennas

	Satellite Model	Туре	Viewing Capability	Automatic	High Definition	Receivers Supported	Compatible Receivers
R O O F M O U N T E D	DISH SK-1000	Stationary	3 Simultaneously	~	~	3	Compatible with all DISH receivers, including Wally and Hopper. (Hopper 1 & 2 installs require nodes/hubs. Hopper 3 requires DISH DPH42 switch.)
	RoadTrip T4 RT2000T, RT2035T	In-Motion	1 at a time	~	~	2	Compatible with ALL DISH receivers except Hopper and Joey.
	DuraSAT D4 CM2000T, CM2035T	In-Motion	1 at a time	~	~	1	Compatible with ALL DISH receivers except Hopper and Joey.
	DISH Playmaker PL-8000, PL-8035	Stationary	1 at a time	•	•	2	Wally, ViP-211k, ViP211z, ViP- 211, ViP-411
	DISH Playmaker PL-7000	Stationary	1 at a time	~	*	1	Wally, ViP-211k, ViP211z, ViP- 211, ViP-411
P O R T A B L E	DISH Playmaker PA-1000	Stationary	1 at a time	~	~	1	Wally, ViP-211k, ViP211z, ViP- 211, ViP-411
	Pathway X1 for DISH	Stationary	1 at a time	~	~	2	Wally, ViP-211k, ViP211z, ViP-211, ViP-411
	Carryout G3	Stationary	1 at a time	~	~	2	Compatible with ALL DISH receivers except Hopper and Joey.
	Carryout G2+	Stationary	1 at a time	~	~	2	Compatible with ALL DISH receivers except Hopper and Joey.

	Pathway X2 for DISH	Stationary	1 at a time	~	~	2	Wally, ViP-211k, ViP211z, ViP-211, ViP-411
	TR-6018 Tripod Kit	Stationary	1 at a time		•	2	Compatible with ALL DISH receivers except Hopper and Joey.
	TR-6100 Tripod Kit	Stationary	3 Simultaneously		~	2	Compatible with all DISH receivers, including Wally and Hopper. (Hopper 1 & 2 installs require nodes/hubs. Hopper 3 requires DISH DPH42 switch.)