

# **SnapPad EQ Installation Instructions**


#### \*\*\*VERY IMPORTANT NOTES\*\*\*

\*\*\*EQUALIZER JACKS CAN BE ROUND OR OCTAGONAL. ENSURE YOU ARE INSTALLING THE CORRECT SNAPPAD ON THE PROPER LANDING FOOT. SEE BELOW\*\*\*

\*\*\*GRAB A HELPER - Installation is safer and easier with 2\*\*\*

### **Equalizer - Octagon**






### **SnapPad EQ Octagon**



EQ Octagon has drainage channels on the bottom with a significant lip compared to SnapPad EQ Zero.

# **Equalizer - Round**



1

The flat round Shaped Equalizer foot works with the smaller SnapPad EQ Zero pad.

### **SnapPad EQ Round**



**EQ** Round is slightly smaller with drainage slots in the lip.



\*\*\*IT IS CRITICAL THAT YOU INSTALL THE CORRECT SNAPPAD ON THE PROPER FOOT. \*\*\*

\*\*\*PLEASE TRIPLE CHECK PRIOR TO INSTALLING YOUR SNAPPADS. PERMANENT DAMAGE COULD RESULT FROM TRYING TO INSTALL ON THE WRONG LANDING FOOT RESULTING IN YOUR WARRANTY BEING VOIDED.\*\*\*

\*\*\*Video instructions can be found on our website <a href="www.rvsnappad.com">www.rvsnappad.com</a> or on YouTube - Search 'SnapPad EQ installation'.\*\*\*

Installation time: 3 - 6 minutes per pad.

- **1.** SnapPad installation is best performed on a level or near level surface preferably a hard surface (concrete or asphalt). Wheel chocks can be placed in front of and behind the RV wheels for additional safety.
- **2.** Grab a helper and use your phone or another person to relay the information between the installer and the person working the controls.
- **3.** Install one at a time. It's important that you align you SnapPads correctly to insure they install correctly and are not damaged during the installation process.
- **4.** \*\*\*Spread a GENEROUS bead of concentrated dish soap or grease around the lip of the SnapPad to aid installation.\*\*\*
- 5. \*\*\*Some motorhomes will release their airbags prior to engaging the jacks. This will lower the entire RV at the beginning of the leveling process. You may place your first SnapPad prior to this, however be careful to not get caught underneath your RV during the lowering process!\*\*\*
- **6.** Once aligned, begin lowering your jack. Keep a watchful eye on the landing foot as it extends. Stop extending when the foot is about 1 to 3 inches from the your SnapPad. **Double check to make sure it is centered.** Re-align as needed and then continue extending the landing gear to complete installation. \*\*\*KEEP YOUR FINGERS AND ANY FOREIGN OBJECTS CLEAR WHEN LOWERING THE JACK INTO PLACE.\*\*\*
- **7.** You should hear a distinctive 'Snap' as the lip engages. \*\*\*Visually confirm the lip is fully engaged around the perimeter of the landing foot.\*\*\*
- **8.** \*\*\*If your lip hasn't fully engaged raise your jack and place a shim (small piece of wood) under the side that hasn't engaged. Lower your jack again until that side snaps into place. Search 'RV SnapPad Uneven Ground Installation' on youtube for an example.\*\*\*
- **9.**Wipe off excess soap or grease and repeat installation process, in sequence, on your remaining jacks.

2



# **Helpful Hints**

3

- It's best (and easiest) to install your SnapPads one at a time on a level, hard surface.
- Each leveling system will have it's own manual operation function. Please refer to your owners manual for specific directions.
- Grab a helper! It's safer, faster, and more efficient with two people
- Install each SnapPad individually and visually confirm the reinforced lip has engaged on the complete diameter. It is critical your SnapPad has been installed fully and correctly.
- Standing water? No problem! Your SnapPads have a built in drainage channel.
- Installs easier in warmer weather. 50 degrees F +.



### **HAVE QUESTIONS OR NEED ASSISTANCE?**

Feel free to contact us anytime.

Phone: 1.855.762.7723

Email: info@rvsnappad.com

website: RVSnapPad.com

### **ON SOCIAL MEDIA?**



@ RVSnapPad



@ SnapPad



@ rv\_snappad



## **SnapPad Info & Statistics**

- Once installed they add an extra 1" to your jack thickness
- You're helping our environment! SnapPads are made from American recycled tires. That means SnapPads are not only durable and versatile but environmentally
- Will work on any type of surface, level or uneven, including: Asphalt - Concrete - Grass - Gravel - Mud -Sand - Resin - Ice - Snow.
- Scientifically tested to maintain integrity at over 10,000 - 20,000 lbs of pressure. (Depending on your version)
- It takes over 1,300 lbs. of vertical pressure to install your SnapPads. This ensures no matter how far off the beaten path you venture, your SnapPads with be there with you.
- Proudly manufactured & shipped from Mishawaka, Indiana, USA!

### **SAFETY**

Your SnapPad's have been tested to withstand over 50x the force of gravity. Which means you could hit the biggest pothole of your life at 60 MPH and your SnapPads will remain firmly fasten to your jacks.

### **HAVE QUESTIONS OR NEED ASSISTANCE?**

Feel free to contact us anytime.

Phone: 1.855.762.7723

Email: info@rvsnappad.com

website: RVSnapPad.com

### **ON SOCIAL MEDIA?**



@ RVSnapPad



@ SnapPad



@ rv\_snappad



#### **Disclaimer**

- SnapPads are an aftermarket RV accessory and as such it is the responsibility of the RV owner to insure they are an appropriate and safe addition to their RV.
- Origen RV Accessories LTD shall not be liable for any special, incidental, indirect or consequential damages whatsoever (including but not limited to, labor, installation, charges, damages to associated equipment, RV, trailer, towing or following vehicle) arising from the use or inability to use or install the product.
- Use extreme caution when installing and using SnapPad. Origen RV Accessories LTD is not responsible or liable in any way for any indirect or direct injury sustained during installation or future use of the product.
- Installing SnapPad products on non-compatible leveling systems will result in the voiding of the warranty and can lead to product failure, property damage, or injury. Origen is not responsible for any issues arising from the use of our products on non-compatible systems.
- SnapPads are designed to be installed once. Do not remove and re-install as this will also void your warranty.

### **Warranty Info**

### What is covered and for how long?

• Origen RV Accessories LTD offers a 2 year extended warranty on both performance and defects in material and workmanship. Should your product fail within a 2 year time frame, Origen RV Accessories LTD will replace your pad free of charge.

#### **Conditions**

- Origen RV Accessories Ltd will replace any defective products within the acceptable 2 year window, starting from the purchase date.
- · Proof of purchase is required.
- Provide an email picture of product defect.
- Should you accidentally order the wrong version ship them back for a full refund.
- Product must be shipped back to Origen RV Accessories Ltd. manufacturing facility at owner expense, meaning you pay the shipping charges
- Ship to: SBMM Attn: Penny Holderman 605 S Laurel St., Mishawaka, IN 46544, USA.
- Origen RV Accessories Ltd reserves the right to refuse any refund for any reason should any of the conditions not be met.

5