

# LEVELMASTER



## Angled Mounting Bracket for fifth wheel Pin Boxes





Figure 1



### Installation instructions:

**Note: Before installation, fifth wheel must be level**

1. Assemble Level Master to bracket components with hardware provided as seen in figure 1. Do not tighten at this time.
2. Position assembly onto pin box at desired location as seen on figure 2. Mark and drill lower front mounting hole on one side. Secure bracket to pin box with a self-tapping screw.
3. Adjust opposite side to a position where the Level Master ball is level. Mark, drill and secure to pin box.
4. Position vertically to desired position. Mark, drill and secure an additional screw per side.