



JUMP STARTER 44

QUICK START GUIDE



GETTING TO KNOW WEEGO 44



CHARGE UP YOUR WEEGO 44

When you unpack your new Weego Jump Starter 44 for the first time, charge it up to 100% with either the wall or car charger provided. Remember to recharge your Weego 44 every 6 months, even when you're not using it – it will help extend its lifespan.

POWERING ON/OFF

There's a Power ON/OFF Button on the back of your Weego 44. While powered "ON", the blue power button will remain illuminated. **Make sure you turn OFF your Weego 44 after every use; leaving it on slowly drains the battery.**




It takes 3 hrs. to fully charge. The indicator lights will flash one by one while the unit is charging. A solid light indicates a completed level of charge.

JUMP STARTING

BEFORE YOU JUMP

- ➔ Read all instructions and safety information prior to using this product. Improper use of this product will void your warranty and may result in product damage, excess heat, toxic fumes, fire, and other unsafe conditions for which Weego is not responsible.
- ➔ Read vehicle owner's manual first: it may have specific cautions and instructions about jumping your engine.
- ➔ This product is for use on **12V Lead-Acid** batteries only! **DO NOT** use this product on any other voltage battery, such as 6V, 24V, etc. **DO NOT** use this product on lithium-ion batteries.
- ➔ Never jump an engine in an enclosed area.
- ➔ Put your vehicle in **PARK** and engage the emergency brake (boats and powersports vehicles should be put in **NEUTRAL**).
- ➔ **TURN OFF ALL ELECTRONICS!** – air conditioner, radio, lights, etc.
- ➔ Remove any devices attached to your Weego 44.
- ➔ Never leave your Weego 44 connected to your engine's battery unless actively jumping.
- ➔ Always disconnect the **Smarty Clamps™** from your Weego 44 when not in use.

WEEGO CUSTOMER SUPPORT We are dedicated to providing the best possible service. To reach Weego Customer Support, visit myweego.com/support or email support@myweego.com.



JUMP STARTING YOUR ENGINE

1. Ensure your engine is completely OFF.
2. Securely connect the **Smarty Clamps™** to your Weego 44, then power ON.
3. Attach **BLACK** clamp to your battery's negative (-) terminal, then the **RED** clamp to your battery's positive (+) terminal. Adjust your **Smarty Clamps™** to achieve MAXIMUM contact with the terminals. Poor connections will prevent you from starting your engine! *Clear off any dirt or buildup with a wire brush or a dry towel before connecting your clamps.*
4. Place your Weego 44 in a secure location or suspend using the provided hook & lanyard so it won't fall. Check your **Smarty Clamps™** lights.
5. When you have a **GREEN READY** light, start your engine. *If the engine doesn't start, turn off your vehicle and check your **Smarty Clamps™** lights.*
6. After a successful start, quickly disconnect the **Smarty Clamps™** from your Weego 44.
7. Detach the **Smarty Clamps™** from the battery.
8. You're now good to go - be sure to run your engine for at least 15 minutes before shutting it off again so it has time to recharge your battery.

If you are having issues getting your engine started, see the **Troubleshooting** section in your owner's manual for further details and assistance.

UNDERSTANDING YOUR *Smarty Clamps*[™]

Your *Smarty Clamps*[™] have a “smart” box that will help guide you through a jump with both sight and sound. It will let you know when it is safe to jump or if there is an error.



● **READY** **Solid green light, no Sound**

Smarty Clamps[™] detect that you have a good connection and you are ready to jump.

●● **REVERSE +/-** **Flashing Green & Red Lights + Beeping**

You attached the *Smarty Clamps*[™] on the wrong terminals. Make sure the **BLACK** clamp is attached to the battery's **NEGATIVE (-)** terminal, and the **RED** clamp is attached to the battery's **POSITIVE (+)** terminal. If not attached properly, Weego 44 will not let you jump your engine.

●● **COOL DOWN** **Flashing Red Light + Beeping** **WAIT FOR** ●

This happens when the battery is cranked longer than the recommended 3 seconds, or if your engine is trying to pull more power than the Weego 44 is willing to provide. Detach the *Smarty Clamps*[™] and give the unit 3 minutes to cool down. Then, repeat steps 2-5 under *Jump Starting Your Engine*.

● **SEE REVERSE** **Solid Red Light, No Sound**

There's a voltage incompatibility. The battery is too weak to even start OR the system voltage of your vehicle is not compatible with your Weego 44 (**for 12V vehicles ONLY**).

● **SEE REVERSE** **Solid Red Light + Beeping**

There may be an engine incompatibility issue. If the engine you're connecting to is larger than what we recommend, it will try to pull more power than your Weego 44 is able to give. If, this happens Weego 44 will prevent you from jumping your engine. Please see *Engine Compatibility* in your owner's manual, to determine if your engine size falls within the scope of Weego 44.



USB CHARGING

Charge your phone, tablet and other portable devices with your Weego 44 using your own USB charging cord. Your Weego 44 comes equipped with **Detect-o-Matic™** USB Charging. This intelligent charger communicates with your device to detect and deliver the fastest-possible charge.



USB Charging Port

To charge your devices, plug your charging cord into your Weego 44 USB port, and connect to your device. Power on your Weego 44 and start charging!

LIGHTING

Your Weego 44 comes with a 500 lumen LED flashlight. Power on your Weego 44, then briefly press and release the flashlight button to initiate the following sequences:

- 1st click: Normal
- 2nd click: Strobe
- 3rd click: SOS
- 4th click: OFF

You can also skip directly to the OFF position by holding down the flashlight button.



Flashlight Button

Your Weego 44 will give you **up to 14 hours of flashlight time** and **up to 28 hours of strobe & SOS light** on a full charge.