
## **SMART TOTE**<sup>2</sup> Owner's Manual



## FILL

Note: Avoid twisting the sewer hose! The bayonet swivels for easy connectivity.

- 1. Remove (A).
- 2. Remove (**B**).
- 3. Pull out (**C**).
- 4. Remove (**D**).
- 5. Hook (E) to coach.
- 6. Empty sewage contents into tank.
- 7. Remove (E) from coach; secure (D) over (E).
- 8. Replace (A).
- 9. Reposition (C) in tank; secure with (B).
- 10. Use the handle (**F**) to hand tow tank.

**NOTE:** A tow handle strap is available to assist with lifting. Refer to (**#9**).

## EMPTY

- 1. Remove (A).
- 2. Remove (B).
- 3. Remove (**C**).
- 4. Remove (D).
- 5. Hook (E) to dump station.
- 6. Hold (**F**) and lift tank until product stands on end; allow tank to drain.

NOTE: To prevent premature emptying, keep hose arched.

- 7. Return tank to ground.
- 8. Remove (G) from (H); insert water hose to run clean water through tank.


TO CLEAN: Remove **(G)** from **(H)**; insert water hose to run clean water through tank.

- 9. Remove hose (E) from dump port.
- 10. Secure (E, D) on (C).
- 11. Reposition (C) in tank; secure with (B).
- 12. Replace (A).



**WARNING:** Not to be used for portable water, gasoline, or any petroleum product. Do not pressurize the tank.

**CAUTION:** Do not exceed walking speed or five MPH during transport. Damage may occur to wheels or tank. This type of damage will void warranty.



Ref. / Part No.			Parts
<b>*</b>			
1	40769	40753	Tank Sewer Hose
2	40530	NA	Vent Cap
3	40757	40531	AutoStopTM Level Gauge Assembly
4	40763	NA	Strap
5 *	40750	40750	Permastore (Sewage) Hosecap
6 *	40751	40751	Bayonet
7 *	40754	40754	Wheel 6" - 1 wheel, axle cap
8	NA	40755	Wheel 8" - 1 wheel, axle cap
9 *	40764	40764	Universal Tow Strap
10 *	40759	40759	Universal Elbow Sewer
11	NA	40761	Accessory Door Top
12	NA	40760	Accessory Door Rear
13	NA	40752	Tow Handle
14	NA	40762	Tow and Front Wheel Kit (4 wheel) Includes items #12, #7, and other item shown)

## Questions? 1-800-543-1219

See your dealer for more information about Thetford products.

Or, write or call:



Thetford Corporation P.O. Box 1285 Ann Arbor, MI 48106 www.thetford.com

info@thetford.com