

120VAC Wiring at Back of Combo Water Heater

The installer must wire up the 120VAC Live, Neutral, & Ground, and is responsible to make a secure connection.

