

# Husky Ball Mount

**Before Towing**, calculate your trailer towing weight including load. Be sure the trailer towing weight does not exceed the weight rating of any component in the towing system. In addition, towing capacity is limited by your vehicle's tow rating; consult the owner's manual for both the tow vehicle and trailer for towing capabilities and safety instructions.

## Installation

1. Insert the ball mount into the receiver, aligning the holes in the shaft of the ball mount with the holes along the side of the receiver.
2. Secure the ball mount with the hitch pin by pushing the hitch pin through both the receiver and ball mount.
3. Secure the hitch pin in place by inserting the safety spring clip through the hole at the end of the hitch pin.

**Note:** Before towing, be sure the hitch ball is properly tightened, and the ball mount is secure in the receiver. Consult the hitch ball manufacturer's instructions for proper procedures.

**Safety chains must be used when towing.** Cross the chains beneath the trailer tongue, forming an "X" beneath the coupler, and attach to the proper points on the tow vehicle. Leave enough slack to allow for turns, but not enough to drag on the ground. Consult the hitch and/or the vehicle manufacturer's instructions for proper attaching points.

