



RV LED Exterior Flood Light Installation Instructions

(Part # 69710)



Product Safety Instructions

IMPORTANT SAFETY INSTRUCTIONS. READ CAREFULLY FOR YOUR PROTECTION AND SAVE ALL INSTRUCTIONS.

- *Disconnect power before installing, adding or changing any component.
- *To avoid a hazard to children, account for all parts and destroy all packing materials.
- *Do not use in damp or wet locations.
- *Do not install any luminaire assembly closer than 6" from any curtain or other combustible material.

SERVICE

There are no user-serviceable parts inside. Opening unit will void warranty.

WARRANTY

For information on our warranty policy please visit our website at <http://www.itc-marine.com/resources/warranty/>

Installation Instructions:

- Step 1: Determine mounting location and drill 1/4" hole for wires.
- Step 2: Attach wires to power source. Black is positive and red is negative.
- Step 3: Hold light to mounting surface and insert and tighten screws until secure.

**LEDs are polarity sensitive and will not light if not attached properly.

