



## Prizm Halogen Overhead Light Installation Instructions

(Part #'s 81290, 81292, & 81295)



### Product Safety Instructions

**IMPORTANT SAFETY INSTRUCTIONS. READ CAREFULLY FOR YOUR PROTECTION AND SAVE ALL INSTRUCTIONS.**

- \*Disconnect power before installing, adding or changing any component.
- \*To avoid a hazard to children, account for all parts and destroy all packing materials.
- \*Do not use in damp or wet locations.
- \*Do not install any luminaire assembly closer than 6" from any curtain or other combustible material.

#### SERVICE

There are no user-serviceable parts inside. Opening unit will void warranty.

#### WARRANTY

For information on our warranty policy please visit our website at <http://www.itc-marine.com/resources/warranty/>

### Installation Instructions:

#### FOR USE AS Recessed MOUNT LIGHT:

- Step 1: Turn bezel counterclockwise to remove
- Step 2: Drill hole in mounting surface with 2.25" hole saw
- Step 3: Attach wires to power source
- Step 4: Install using included screws
- Step 5: Turn bezel clockwise to replace

#### FOR USE AS SURFACE MOUNT LIGHT:

- Step 1: Turn bezel counterclockwise to remove
- Step 2: Drill hole in mounting surface for wires
- Step 3: Attach wires to power source
- Step 4: Install using included screws
- Step 5: Turn bezel clockwise to replace

\*LEDs are polarity sensitive. If the wires are not connected correctly, the LED will fail to light.

