



AIR BOX WIRING DIAGRAM

EasyStart



115 VAC 60 HZ, 1Ø
USE COPPER CONDUCTORS ONLY

FACTORY WIRING _____
FIELD WIRING . . .
LINE SPLICE .

SWITCH CONNECTION		
OFF		L1-1-C
HI FAN	L1-1	MED COOL
MED FAN	L1-2	LOW COOL
LOW FAN	L1-4	HEAT
		L1-4-H