LAGUN TABLE LEG

Lagun





INSTALLATION INSTRUCTIONS

- Tabletop Mounting Plate
- Arm (Horizontal piece)
- Leg (Vertical piece)
- Mounting Bracket Plate
- Hardware Kit (1-Teak Board/2 Wedges/ 4 ea. SS Bolts, washers & nuts)

TOOLS NEEDED

- 12V Power Drill Gun
- ¼″ Drill Bit
- Phillip Drive Bit
- 6 Screws for Tabletop Mounting Plate (Not Provided) NOTE: Must be shorter than your tabletop
 - thickness

OPERATING INSTRUCTIONS

TOP LEFT HAND HANDLE

• Releases the tabletop to swivel 360 degrees

TOP RIGHT HAND HANDLE

Releases the complete system to swivel 360 degrees

BOTTOM HANDLE

- Releases the vertical height adjustment
- Be careful when releasing as gravity will pull it down

ALL HANDLES:

- ALL Handles <u>Untighten</u> counterclockwise
- ALL Handles <u>Tighten</u> clockwise
- Pushing the button on the handle in allows you to reposition the handle and continue to tighten it.

- Choose a solid vertical surface to install the mounting bracket plate. NOTE: Make sure there is enough clearance to be able to adjust the leg up and down. Some RV dinette cushions stick out, so you may need to use the provided hardware kit to be able to clear them. Use the supplied teak board and/or shims to make the mounting bracket is straight. Use the enclosed bolts to bolt the mounting plate to your solid vertical surface. If the bolts due not work for your application, you can use a 5/16" tapered screws to attach the mounting plate. NOTE: Make sure the screws or bolts you choose to use will not protrude into or through something before drilling or screwing out the plate.
- Flip your tabletop upside down and install the tabletop mounting plate to your tabletop.
 NOTE: Make sure that the screws you use are shorter than your tabletop thickness, so you don't go through the tabletop.
- Install the arm to your tabletop mounting plate by sliding it over the splined piece. (You may have to move it back and forth to slide it on the splined piece) NOTE: Make sure the splined piece from the tabletop mounting plate is inserted completely, so it is flush with the bushing on the arm.
- Install the splined piece of the leg into the bushing on the other end of the arm. (You may have to move it back and forth to slide it on the splined piece) NOTE: Make sure the splined piece from the leg is inserted completely, so it is flush with the bushing on the arm.
- Once it is all assembled, lock all the handles and flip it upright. Make sure the bottom handle on the leg is untightened and slide the leg on the mounting bracket plate and tighten handle.

•THE LAGUN TABLE LEG CAN SUPPORT 50 LBS OF WEIGHT INCLUDING YOUR TABLETOP •1 YEAR WARRANTY FROM MANUFACTURER DEFECTS •MODIFICATIONS TO THE LAGUN TABLE LEG VOIDS YOUR WARRANTY