

Instructions: Deluxe Folding Camping Trailer Cover

⚠️ WARNING!

Installation is best done with two people and on most RVs requires working from the roof of the RV. **Never install on a windy day or when the RV roof is slippery. Please take care when you are on a ladder or the roof.**

CAUTION

Please consult your RV owners manual.

Installation

- 1.** Fold your camping trailer down and secure it. Cover or tape any sharp edges on your trailer that could wear against your cover.
- 2.** Find the Classic logo on your cover – this is the front. Slip your Folding Camping Trailer Cover over the top of your trailer then pull the elasticized bottom hem down along the bottom edge of the trailer.
- 3.** Tie an end of one of the supplied pre-cut ropes onto one of the D-rings along the bottom hem. Put a small rock in the provided toss bag, close the top and tie the free end of the rope to the bag D-ring. Now toss the bag and rope under your RV to the D-ring on the opposite side. Take the rope off the bag and tie it to the D-ring. Repeat with remaining D-rings.

Use and Storage

A handy storage bag is provided. To fit your cover in the bag fold and roll it tightly rather than stuffing it. Never store a wet cover in the storage bag or confined area as the cover can be damaged by mildew.



Care

Spot clean with water, a mild soap and a sponge. Don't use abrasive cleaners or brushes.

Three Year Limited Warranty

If this cover fails due to a defect in workmanship and materials within three years from the date of purchase, Classic Accessories will repair or replace it free of charge Trailering or towing with your

Folding Camping Trailer Cover on will invalidate the warranty.

This warranty gives you specific rights and you may also have other rights which vary from state to state.



Classic Accessories, Inc.
Kent, WA, USA 98032
www.classicaccessories.com