

TowMate®

"World's Only Full Functioning
Wireless Taillight System"

TowMate Wireless RV Towlight Guide to Operations



Thank you for purchasing a TowMate wireless tow light!

System Features:


- Your complete system should include:
 - The Light, Transmitter (the sending unit that plugs into the RV), a Cigarette Lighter Charge Cord (DC charger), a smart charger (AC Charger), and a carrying case.
 - Additional options include: suction cup base, solar panel, and iMON interactive monitoring system.
- High performance electronics provide optimum range and reliability.
 - 1,000 feet of 'line-of-sight' range.
 - Injection molding keeps the electronics completely sealed from the elements such as moisture, corrosion, or vibration damage.
- Lifetime Warranty
 - Covers Electronics and LED's
 - If ever the light fails to get a signal or an LED burns out, TowMate will replace the defective component at **no cost**.
- I-MON Compatible
 - Never leave your light behind again with the new I-MON Interactive Monitoring System available now!



General Operating Tips:

1. First, plug the transmitter into the receptacle on the RV.
2. Power the light on by flipping the On/Off switch to the 'On' position.
 - a. The light will go through a brief flash sequence indicating what series of electronics are in the unit (useful when servicing or replacing parts).
3. The Light should now be fully operational for Wireless S/T/T signals.
4. Use either of the charge cords provided to recharge the unit.
 - a. It takes 6-8 hours to fully recharge the battery in the light.
 - b. You cannot overcharge the unit using the provided chargers.
 - c. The battery in the unit should have a total life of 1-2 years.
 - i. If a battery dies prior to the expected 12 month lifetime, TowMate may choose to warranty (generally under 6 months), or pro-rate (6-12 months), the replacement.
 - ii. If your light appears to have a low battery or will not take a charge, be sure that the fuse in the tip of the charge cord plug is still intact. If it is blown, replace with a 10-20 amp fuse.
5. Always check to be sure that the light is securely fastened to the load you are hauling.
 - a. Though the rubber coated 105 Lb. pull magnets are strong, they will not hold on aluminum or fiber glass surfaces ☺

7-Pin RV Wiring



*** This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.*