TOAD-CHARGE



Towed Vehicle Battery Charger

GENERAL INFORMATION — **TOAD-CHARGE[™]** keeps the battery in your towed vehicle (or "Toad") charged while it is being towed behind your motorhome. The kit connects between your motorhome's starting or house batteries and the towed vehicle's battery, using the motorhome's engine to supply up to 10 amps of current to the towed vehicle's battery. The kit consists of a Charge Controller installed in the towed (or "Dinghy") vehicle's engine compartment, a 15 Amp Circuit Breaker installed near the motorhome starting battery, and a cut-to-length 40 or 60 foot wire harnesses with user-installed connectors.



STEP 8 - INSTALL THE TOW BAR WIRE HARNESS: With your tow bar attached and extended in the same manner as it would be when towing your dinghy vehicle, take the surplus harness left over from STEP 5 and use LARGE zip-ties to attach it from one end of the tow bar to the other (i.e., from dinghy vehicle to motor home). Cut off any excess harness, making sure to leave enough of it dangling at both ends to reach the connectors on the motor home and dinghy vehicle under ALL driving and stowage conditions. If your tow bar folds sideways or telescopes, make sure that it doesn't pinch the harness when folded or retracted.

Next, attach MALE (larger) connectors to both ends of this tow bar harness, taking care to match the red wires with their corresponding red dots on the connectors:



STEP 9 - TEST THE SYSTEM FOR PROPER OPERATION: Re-connect the motorhome and dinghy negative battery cables to their battery posts, mate the tow bar harness with its corresponding connectors on the dinghy vehicle and motorhome hitch, start the motorhome engine, and confirm that the yellow CHARGING light on the Charge Regulator glows steady - If not, refer to the TROUBLESHOOTING section below. Next, unplug all the connectors to allow installation of the shrink tubing.

□ STEP 10 - INSTALL SHRINK TUBING: Temporarily mate a spare Female connector with the Male connector on the motorhome end of the tow bar wire harness:



Cut a 2" piece of red heat-shrink tubing, and slide it over the Male connector:



one of the connectors at the end of a harness.

□ STEP 11 - INSTALL THE CONNECTOR DUST CAPS:

Slide the open end of a bead chain through the slit in

one of the red vinyl dust caps, and then use the joiner

on the chain to connect both ends of the chain together.

Next, use a small zip tie to secure the bead chain near

Use a heat gun* to apply heat to all areas of the shrink tubing, so that it shrinks down to the shape of the Male connector and harness wire:



Remove the spare Female tubing connector after the cools.

NOTE: Use the LOW (750 watt) heat gur setting. If a heat gun is not available, use a butane lighter or torch to **GENTLY** heat the tubing – Work slowly, to avoid scorching it before it has time to shrink

Slide another 2" piece of heat-shrink tubing over the Female connector on the back of the motorhome before mating it with the tow bar connector you previously shrunk tubing over:



Operation & Maintenance

Joiner

The green POWER light confirms that the Charge Controller is receiving DC power from the motorhome, and will turn off shortly after the dinghy is unplugged from the motorhome. The Yellow CHARGING light confirms that the motor home is supplying sufficient voltage to charge the dinghy battery (13.25 volts or greater), and will turn off shortly after the motorhome engine is shut off.

Periodic maintenance consists of: (1.) cleaning the connectors (a spray can of WD-40® works well for this task), and (2.) inspecting the harness for cuts or nicks. Any connectors not in use should be covered by their protective dust caps.

Troubleshooting - In Case Of Problems

SYMPTOM - No green POWER light (or yellow CHARGING light is flashing) when dinghy & motorhome are connected: Check for loose wire crimp connections on the ring terminals at the motor home battery and 15 Amp Circuit Breaker, and for loose wire screws on the Charge Controller, dinghy vehicle battery posts, and all plug-in connectors on the wire harness.

SYMPTOM - No yellow CHARGING light when motor home engine is running: Check to see if motorhome starting and/or house batteries are heavily discharged - Since first priority is given to recharging these batteries, the voltage produced by the motorhome engine may not be high enough to turn on the Charge Controller until these other batteries have had a chance to accept some charge.

SYMPTOM - Green POWER and Yellow CHARGING lights are alternately flashing: Indicates that the Charge Controller is not connected to the dinghy vehicle battery. Check for loose connections on the Charge Controller and dinghy battery cable bolts.

SYMPTOM - Red REV POL light is on: Indicates reverse polarity (incorrect installation). Check for reversed wire connections at the motor home battery posts, all 4 plug-in connectors, the Charge Controller terminals, and the dinghy battery posts.

This product has a **ONE YEAR** warranty against defects. For service, repair parts or technical support, please contact:

L S L PRODUCTS • 5804 BABCOCK RD. # 512 • SAN ANTONIO, TX 78240 • 877-257-4655 • www.LSLProducts.net ©2003-2014 LSL Products All Rights Reserved Page 2 of 2