

Instructions for Brake Assembly Kit 7", 10" and 12" Electric or Hydraulic Brakes

Notice to Buyer

It is recommended that all brakes be replaced at the same time to insure balanced braking performance.

Remove the old brakes

1. Jack up trailer and secure on adequate capacity jack stands. Follow trailer manufacturers recommendations for lifting and supporting the unit. Check that the wheel and drum rotate freely.



Do not lift or place supports on any part of the suspension system. Never crawl under your trailer unless it is resting on properly placed jack stands.

- 2. Remove the wheel and drum from the spindle, leaving the brake exposed. Check armature surface and drum braking surface; resurface if required see operation maintenance manual for refinishing limits.
- 3. Disconnect the brake actuation system. For electric brakes: cut the magnet wire and remove the strain relief from the dust shield. For hydraulic brakes: remove the hydraulic brake line from the wheel cylinder.
- 4. Then remove the brake mounting hardware. Remove the old complete brake assembly. Save the brake mounting hardware for installing the new brake.

Installing the new brakes

1. Install the new brake assembly using the old hardware. If new hardware is required (or desired) select the correct components according to your brake size from the chart below:

<u>Brake Size</u> 7"	<u>Qty</u> 4	<u>PN</u> 006-017-00	<u>Description</u> 7/16" – 20 Hex Nut TORQUE 45 - 70 ft. lbs.
10"	4	006-017-00	7/16" – 20 Hex Nut TORQUE 45 - 70 ft. lbs.
12"	5 5	006-010-00 005-004-00	3/8" - 24 Hex Nut TORQUE 25 - 50 ft. lbs. 3/8" Lock Washer

- 2. Reconnect the brake actuation system. Refer to your *Operation Maintenance Service Manual* for proper connection.
- 3. Remount the drum and wheel. Refer to your *Operation Maintenance Service Manual* for proper bearing adjustment procedure.
- 4. Burnish in the new brake shoes. Then properly adjust the brakes per the *Operation Maintenance Service Manual* if the brakes are manual adjust.

March 18, 2002 059-726-00 Rev. A